an EnerSys® company

Cordex® CXPS-E3

Edge Power System

User Guide

Document ID: 9400016-J0
Effective: 09/2026



Read this document carefully.
Learn how to protect your equipment from damage and fully understand its functions.

NOTICE

The material contained in this document is for information only and is subject to change without notice.

Contents

1. Safety 5
   - 1.1 Safety symbols 5
   - 1.2 General warnings and cautions 5
   - 1.3 Electrical safety 6
   - 1.4 Battery safety 7
   - 1.5 Installation and safety precautions 7
   - 1.6 Lifting 7
   - 1.7 Radiation exposure statement 8
   - 1.8 Déclaration d'exposition aux radiations 8
2. Introduction 9
   - 2.1 Document scope 9
   - 2.2 Product overview 9
   - 2.3 System configurations 10
3. Specifications 16
   - 3.1 Cordex® CXPS-E3 300 A Edge Power System 16
   - 3.2 Cordex® CXPS-E3 400 A Edge Power System 17
   - 3.3 Cordex® CXPS-E3 600 A Edge Power System 19
   - 3.5 Cordex® CXPS-E3 600 A Edge Power System (Double Distribution) 20
   - 3.4 Cordex® CXPS-E3 900 A Edge Power System 21
4. Features 22
   - 4.1 Seismic racks 22
   - 4.2 Distribution panels 22
   - 4.3 Control and monitoring methods 24
   - 4.4 EnVision™ Elite Touch Controller 25
   - 4.5 Front panel with controller and ADIO peripheral 26
   - 4.6 Cordex® HP 2.4 kW Rectifier Module 29
   - 4.7 Cordex® HP 3.0 kW Rectifier Module 29
   - 4.8 Cordex® HP 4.0 kW Rectifier Module 29
   - 4.9 Cordex® HP 4.6 kW Rectifier Module 29
   - 4.10 Rectifier module front panel LEDs 30

4.11 300, 400, and 600 A LVD override 30
4.12 600 A LVD override 32
4.13 Integrated battery trays 35
4.14 Battery landing busbar kit 35

5. Inspection 37
5.1 Packaging materials 37
5.2 Returns for service 37
5.3 Check for damage 37
5.4 General receipt of shipment 37
5.5 Miscellaneous small parts 37

6. Installation 38
6.1 Safety precautions 38
6.2 Tools required 38
6.3 Installation of external batteries 38
6.4 Battery maintenance report 40
6.5 Power system assembly and mounting 41
6.6 Breaker installation 43

7. Wiring 44
7.1 Installation notes 44
7.2 Grounding 45
7.3 AC wiring 48
7.4 DC wiring 50
7.5 Distribution cabling 51
7.6 Alarm and signal connection 52
7.7 Network and remote communication 54
7.8 Connecting battery temperature sensor 54
7.9 Signal wiring 55

8. System startup 56

9. Maintenance 58
9.1 System controller lithium battery replacement 59
9.2 300 and 400 A LVD override operation 60
9.3 600 A LVD override operation 60

10. Troubleshooting 61
10.1 Cordex® HP Rectifier Module LEDs 61
10.2 EnVision™ Elite Touch Controller LEDs 61
10.3 Cordex® CXC HP System Controller LEDs 62
10.4 Cordex® HP L-ADIO Low Voltage Smart Peripheral LEDs 62
10.5 LVD Override Board LEDs 63
11. Technical drawings 64

1. Safety

Save these instructions

This document contains important safety instructions that must be followed during the installation, servicing, and maintenance of the product. Keep it in a safe place. Review the drawings and illustrations contained in this document before proceeding. If there are any questions regarding the safe installation or operation of this product, contact Alpha Technologies Ltd. or the nearest Alpha® power system representative.

1.1 Safety symbols

To reduce the risk of injury or death, and to ensure the continued safe operation of this product, the following symbols have been placed throughout this document. Where these symbols appear, use extra care and attention.

Symbol	Type	Description
	**WARNING**	Risk of serious injury or death Equipment in operation poses a potential electrical hazard which could result in serious injury or death to personnel. This hazard may continue even when power is disconnected.
	**CAUTION**	Cautions indicate the potential for injury to personnel or damage to equipment.
	**CAUTION**	Risk of burns A device in operation can reach temperature levels which could cause burns.
	**ATTENTION**	The use of attention indicates specific regulatory or code requirements that may affect the placement of equipment or installation procedures. Follow the prescribed procedures to avoid equipment damage or service interruption.
	**GROUNDING**	This symbol indicates the location or terminal intended for the connection to protective earth. An system that is not properly connected to protective earth presents an electrical hazard. Only a licensed electrician can connect AC power and protective earth to the enclosure.
	**NOTICE**	A notice provides additional information to help complete a specific task or procedure or general information about the product.

1.2 General warnings and cautions



WARNING

You must read and understand the following warnings before installing the enclosure and its component. Failure to do so could result in personal injury or death.

- **Read and follow all instructions included in this document.**
- **Only trained personnel are qualified to install or replace this equipment and its components.**
- **Use proper lifting techniques whenever handling equipment, parts, or batteries.**

WARNING

This system is designed to be installed in a restricted access location that is inaccessible to the general public.

AVERTISSEMENT

Ce système est conçu pour être installé dans un endroit à accès restreint inaccessible au grand public.

WARNING

This equipment is not suitable for use in locations where children are likely to be present.

AVERTISSEMENT

Cet équipement ne convient pas pour une utilisation dans des lieux ou des enfants sont susceptibles d'être présents.

1.3 Electrical safety

WARNING

Hazardous voltages are present at the input of power systems. The DC output from rectifier modules, though not dangerous in voltage, has a high short-circuit current capacity that can cause severe burns and electrical arcing.

The DC output from converter modules is a potentially hazardous voltage. Do not touch the output connections when under power. Ensure that power has been removed from the outputs before working on them.

Before working with any live battery or power system, follow these precautions:

- Remove all metallic jewelry, such as watches, rings, metal rimmed glasses, or necklaces.
- Wear safety glasses with side shields at all times during the installation.
- Use Occupational Safety and Health Administration (OSHA®) insulated hand tools. Do not rest tools on top of batteries.

WARNING

Lethal voltages are present within the power system. Always assume that an electrical connection or conductor is energized. Check the circuit with a voltmeter with respect to the grounded portion of the enclosure (both AC and DC) before performing any installation or removal procedure.

- Do not work alone under hazardous conditions.
- A licensed electrician is required to install permanently wired equipment. Input voltages can range up to 480 VAC. Ensure the utility power is disconnected and locked out before performing any installation or removal procedure.
- Ensure that no liquids or wet clothes come into contact with internal components.
- Hazardous electrically live parts inside this unit are energized from the batteries even when the AC input power is disconnected.

WARNING

High leakage current

Earth connection is essential before connecting the power supply.

1.4 Battery safety



WARNING

Follow the battery manufacturer's safety recommendations when working around battery systems. Do not smoke or introduce an open flame when batteries (especially vented batteries) are charging. When charging, batteries vent hydrogen gas, which can explode.

Batteries are hazardous to the environment and should be disposed at a recycling facility. Consult the battery manufacturer for recommended local authorized recyclers.



ATTENTION

Battery safety data sheets

Read the battery safety data sheet (SDS) before installing batteries in the power system. The SDS provides important information including hazard identification, first aid measures, handling and storage, and personal protective equipment (PPE).

1.5 Installation and safety precautions

- Only qualified personnel should install and connect the power components within the power system.
- Make sure to connect the protective earthing (master grounding) terminal within the AC load center of the equipment to the earth point in the building installation or the site reference ground.
- Only install the power system using the mounting hardware provided by Alpha Technologies Ltd.

1.6 Lifting



CAUTION

Follow all local safety practices and guidelines while lifting the enclosure. All personnel involved with lifting and positioning the enclosure must wear head and eye protection, and gloves. Only properly trained and certified personnel should operate the crane. Only properly trained and certified personnel should operate the forklift.

Before lifting the power system into place:

- Ensure the modules are not installed.
- The distribution panel door is firmly affixed.
- Open and latch the enclosure front door.

1.7 Radiation exposure statement



CAUTION

FCC radio-frequency radiation exposure statement

This equipment complies with FCC radio-frequency radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

The device complies with radio-frequency specifications when the device used at >7.9 inches (20 cm) from your body.



CAUTION

This equipment complies with Innovation, Science and Economic Development Canada (ISED) radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance >7.9 inches (20 cm) between the radiator and your body.

1.8 Déclaration d'exposition aux radiations



PRUDENCE

Cet équipement est conforme aux limites d'exposition aux rayonnements Innovation, Sciences et Développement économique Canada (ISDE) établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de >7.9 pouces (20 cm) de distance entre la source de rayonnement et votre corps.

2. Introduction

2.1 Document scope

This document covers the features, options, installation, and startup of the Cordex® CXPS-E3 edge power system. Images contained in this document are for illustrative purposes only and may not exactly match your installation. To assist with installation, refer to the drawings at the end of this document.

In addition to this document, the following may be included in the documentation package that ships with the power system:

- EnVision™ Elite Controller Software Manual (ID: 0350189-J0)
- Cordex® HP System Controller Software Manual (ID: 0350058-J0)
- Cordex® HP 2.4/3.0 kW Rectifier Module User Guide (ID: 0100037-J0)
- Cordex® HP 4.0/4.6 kW Rectifier Module User Guide (ID: 9400000-J0)

2.2 Product overview

The Cordex® CXPS-E3 edge power system uses high-density rectifier modules, a front-access distribution panel, and the advanced EnVision™ Elite Touch controller or Cordex® HP system controller. The power system is the ideal solution for small to medium-sized 48 VDC applications, providing up to 900 A of output current. With universal 19-inch or 23-inch mounting, high temperature operation, and high power density, it is the perfect solution for a wide variety of installation scenarios including those in harsh, outdoor environments. The distribution panel provides up to 52 load breaker positions, integrated shunt, and optional low voltage battery disconnect (LVBD). All distribution connections and controller I/O contacts are front-accessible.

The controller includes a touchscreen display for simple and convenient local setup. A built-in web server provides alternate setup via local or remote IP access, using a standard internet browser. Power systems can be easily integrated into customer provided relay racks or enclosures, or can be ordered factory installed into various Alpha® relay rack configurations, including power systems with pre-wired battery trays.

- Integrated 48 V 300, 400, 600, or 900 A power systems with front-access distribution
- Industry leading power system density
- Up to 900 A and 52 distribution positions
- Advanced EnVision™ Elite Touch controller or Cordex® HP system controller with touchscreen display panel for full local control and a pre-wired Cordex® HP L-ADIO low voltage analog and digital input and output (ADIO) peripheral
- High temperature rated design for harsh outdoor applications
- Wide range AC input for flexible worldwide deployment

1. Front access distribution panel
2. Controller and ADIO module panel
3. High-density rectifier modules




Figure 1: Cordex® CXPS-E3 400 A edge power system (19-inch)

2.3 System configurations

The following configurations are currently available for Cordex® CXPS-E3 edge power systems. For more ordering information, refer to the Cordex® CXPS-E3 Edge Power System Ordering Guide (ID: 0470209-00).

Table A: System configurations

Current rating	Rectifier module capacity	Load breakers	Battery breakers	Shunts	LVBD	Height
19-inch racks						
300 A	4 × 2.4/3.0 kW rectifier modules; 1 × shelf	21	0	Load		4RU
		16	5	Battery	Optional	
400 A	8 × 2.4/3.0 kW rectifier modules; 2 × shelves	21	0	Load		5RU
		16	5	Battery	Optional	
400 A	5 × 4.0/4.6 kW rectifier modules; 1 × shelf	21	0	Load		7RU
		16	5	Battery	Optional	
23-inch racks						
300 A	5 × 2.4/3.0 kW rectifier modules; 1 × shelf	21	0	Load		4RU
		16	5	Battery	Optional	
400 A	6 ×4.0/4.6 kW rectifier modules; 1 × shelf	26	0	Load		7RU
		21	5	Battery	Optional	
600 A	10 × 2.4/3.0 kW rectifier modules; 2 × shelves	26	0	Load		5RU
		26		Battery	Optional	
600 A	10 × 2.4/3.0 kW rectifier modules; 2 × shelves	52	0	Load × 2		10RU
		52		Battery	Optional	
900 A	15 × 2.4/3.0 kW rectifier modules; 3 × shelves	52	0	Load × 2		11RU
900 A	15 × 2.4/3.0 kW rectifier modules; 3 × shelves	52	0	Load × 2		11RU

2.3.1 300 A power system (19-inch) with one 2.4/3.0 kW rectifier shelf

- EnVision™ Elite Touch controller or Cordex® CXC HP system controller
- Cordex® HP L-ADIO low voltage smart peripheral with extensive I/O capability
- Cordex® HP 2.4/3.0 kW rectifier shelf with up to four module positions; 4RU form factor
- **Current rating:** 300 A
- 21 load breakers with load shunt or 16 load and five battery breakers with LVBD
- Option for battery LVD for battery breaker configuration




Figure 2: Cordex® CXPS-E3 300 A edge power system (19-inch) with one 2.4/3.0 kW rectifier shelf

2.3.2 300 A power system (23-inch) with one 2.4/3.0 kW rectifier shelf

- EnVision™ Elite Touch controller or Cordex® CXC HP system controller
- Cordex® HP L-ADIO low voltage smart peripheral with extensive I/O capability
- Cordex® HP 2.4/3.0 kW rectifier shelf with up to five module positions; 4RU form factor
- **Current rating:** 300 A
- 21 load breakers with load shunt or 16 load and five battery breakers with LVBD
- Option for battery LVD for battery breaker configuration




Figure 3: Cordex® CXPS-E3 300 A edge power system (23-inch) with one 2.4/3.0 kW rectifier shelf

2.3.3 400 A power system (19-inch) with two 2.4/3.0 kW rectifier shelves

- EnVision™ Elite Touch controller or Cordex® CXC HP system controller
- Cordex® HP L-ADIO low voltage smart peripheral with extensive I/O capability
- Two Cordex® HP 2.4/3.0 kW rectifier shelves with up to eight module positions; 5RU form factor
- **Current rating:** 400 A
- 21 load breakers with load shunt or 16 load and five battery breakers with LVBD
- Option for battery LVD for battery breaker configuration




Figure 4: Cordex® CXPS-E3 400 A edge power system (19-inch) with two 2.4/3.0 kW rectifier shelves

2.3.5 400 A power system (23-inch) with two 2.4/3.0 kW rectifier shelves

- EnVision™ Elite Touch controller or Cordex® CXC HP system controller
- Cordex® HP L-ADIO low voltage smart peripheral with extensive I/O capability
- Two Cordex® HP 2.4/3.0 kW rectifier shelves with up to 10 module positions; 5RU form factor
- **Current rating:** 400 A load
- 26 load breakers with load shunt or 21 load and five battery breakers with LVBD
- Option for battery LVD for battery breaker configuration




Figure 6: Cordex® CXPS-E3 400 A edge power system (23-inch) with two 2.4/3.0 kW rectifier shelves

2.3.4 400 A power system (19-inch) with one 4.0/4.6 kW rectifier shelf

- EnVision™ Elite Touch controller or Cordex® CXC HP system controller
- Cordex® HP L-ADIO low voltage smart peripheral with extensive I/O capability
- Cordex® HP 4.0/4.6 kW rectifier shelf with up to five module positions; 7RU form factor
- **Current rating:** 400 A
- 21 load breakers with load shunt or 16 load and five battery breakers with LVBD
- Option for battery LVD for battery breaker configuration




Figure 5: Cordex® CXPS-E3 400 A edge power system (19-inch) with one 4.0/4.6 kW rectifier shelf

2.3.6 400 A power system (23-inch) with one 4.0/4.6 kW rectifier shelf

- EnVision™ Elite Touch controller or Cordex® CXC HP system controller
- Cordex® HP L-ADIO low voltage smart peripheral with extensive I/O capability
- Cordex® HP 4.0/4.6 kW rectifier shelf with up to six module positions; 7RU form factor
- **Current rating:** 400 A
- 26 load breakers with load shunt or 21 load and five battery breakers with battery LVD
- Option for battery LVD for battery breaker configuration
- Option for different AC input configurations individual feed, 208 VAC three phase or 480/277 VAC three phase




Figure 7: Cordex® CXPS-E3 400 A edge power system (23-inch) with one 4.0/4.6 kW rectifier shelf

2.3.7 600 A power system (23-inch) with two 2.4/3.0 kW rectifier shelves

- EnVision™ Elite Touch controller or Cordex® CXC HP system controller
- Cordex® HP L-ADIO low voltage smart peripheral with extensive I/O capability
- Two Cordex® HP 2.4/3.0 kW rectifier shelves with up to 10 module positions; 5RU form factor
- **Current rating:** 600 A
- 26 load breakers with load shunt or 26 load breakers with battery shunt and battery LVD
- Choice of eight 2 AWG (35 mm²) battery landing busbars or two 350 kcmil (185 mm²) battery landing busbars




Figure 8: Cordex® CXPS-E3 600 A edge power system (23-inch) with two 2.4/3.0 kW rectifier shelves

2.3.8 600 A power system (23-inch) with double distribution and two 2.4/3.0 kW rectifier shelves

- EnVision™ Elite Touch controller or Cordex® CXC HP system controller
- Cordex® HP L-ADIO low voltage smart peripheral with extensive I/O capability
- Two Cordex® HP 2.4/3.0 kW rectifier shelves with up to 10 module positions; 10RU form factor
- **Current rating:** 600 A
- 52 load breakers with load shunt or 52 load breakers with battery shunt and battery LVD
- Busbar landings accommodate up to two 4/0 AWG (120 mm²) cables and up to four 2 AWG (35 mm²) cables




Figure 9: Cordex® CXPS-E3 600 A edge power system (23-inch) with two 2.4/3.0 kW rectifier shelves

NOTICE

This system can be equipped from factory with an optional 10 position 30 A rated GMT fuse board.

NOTICE

There are three configurations for this power system:

- 2 × load LVD (one load LVD for each distribution tier with support for non-critical load shedding)
- 1 × latching battery LVD
- No LVD

2.3.9 900 A power system (23-inch) with double distribution and three 2.4/3.0 kW rectifier shelves

- EnVision™ Elite Touch controller or Cordex® CXC HP system controller
- Cordex® HP L-ADIO low voltage smart peripheral with extensive I/O capability
- Three Cordex® HP 2.4/3.0 kW rectifier shelves with up to 15 module positions; 11RU form factor
- **Current rating:** 900 A (450 A per distribution tier)
- 52 load breakers




Figure 10: Cordex® CXPS-E3 900 A edge power system (23-inch) with three 2.4/3.0 kW rectifier shelves

3. Specifications

3.1 Cordex® CXPS-E3 300 A Edge Power System

Table B: 48 V–3.0 kW Cordex® CXPS-E3 300 A edge power system

Electrical		
		48 V-3.0 kW rectifier system
System capacity (maximum)		300 A
Input	**Operating voltage**	208 to 277 VAC (nominal)
	Extended (high)	277 to 310 VAC (derated output power)
	Extended (low)	90 to 187 VAC (derated output power)
	Recommended AC breakers	**19-inch system:** Up to 4 × 20 A feeds
		23-inch system: Up to 2 × 40 A feeds and 1 × 20 A feeds
	Efficiency	>96.1% peak efficiency
Output	**Current per module**	62.5 A at 48 VDC (nominal) 32 A maximum at 48 VDC (120 VAC)
	Rectifier module positions	**19-inch system:** Up to 4 rectifier modules
		23-inch system: Up to 5 rectifier modules
Mechanical		
19-inch system	**Mounting**	Flush or center mount
	Dimensions (H × W × D)	7 × 19 × 17 in. (178 × 482 × 432 mm)
	Hot positions	21 load breakers or 16 load and 5 battery breakers
		21 sets of 0.25-inch studs on 0.625-inch centers
	Return positions	21 sets of 0.25-inch studs on 0.625-inch centers
	Net weight (system)	35.1 lb (15.9 kg)
23-inch system	**Mounting**	Flush or center mount
	Dimensions (H × W × D)	8 × 23 × 17 in. (203 × 584.2 × 432 mm)
	Hot positions	26 load breakers or 21 load and 5 battery breakers
		26 sets of 0.25-inch studs on 0.625-inch centers
	Return positions	26 sets of 0.25-inch studs on 0.625-inch centers
	Net weight (system)	44.4 lb (20.1 kg)
Net weight (rectifier module)		3.9 lb (1.76 kg) per module
System access		Front-access after initial installation
Controller		EnVision™ Elite Touch controller
		Cordex® CXC HP system controller
Environmental		
Operating temperature		–40 to 131°F (–40 to 55°C); –40 to 149°F (55 to 65°C) derated at 104°F (40°C)
Storage temperature		–40 to 185°F (–40 to 85°C)

Relative humidity	0 to 95% non-condensing
Elevation	Up to 6,600 ft (2,000 m)
	Up to 9,843 ft (3,000 m) with derated output
Cooling	Fan-cooled (front to rear)
Heat dissipation	585 BTU/h (171 W) per module maximum
Regulatory compliance	
Safety	CAN/CSA-C22.2 No. 60950-1-07
	UL 60950-1

3.2 Cordex® CXPS-E3 400 A Edge Power System

Table C: 48 V–2.4/3.0 kW, 4.0/4.6 kW Cordex® CXPS-E3 400 A edge power system

Electrical			
		48 V-2.4/3.0 kW rectifier system	**48 V-4.0/4.6 kW rectifier system**
System capacity (maximum)		400 A	
Input	**Operating voltage**	208 to 277 VAC (nominal)	208 to 277 VAC
			Three-phase 208 to 240 VAC
			Three-phase 277/480 VAC
	Extended (high)	277 to 310 VAC (derated output power)	
	Extended (low)	90 to 187 VAC (derated output power)	
	Recommended AC breakers	**19-inch system:** Up to 8 × 20 A feeds	**19-inch system:** Up to 5 × 30 A feeds (208 to 277 VAC single phase)
		23-inch system: Up to 4 × 40 A feeds and 2 × 20 A feeds	**23-inch system:** Up to 6 × 30 A feeds (208 to 277 VAC single phase)
			Up to 2 × 50 A feeds (208 VAC three-phase)
			Up to 2 × 30 A feeds (480/277 VAC three-phase)
	Efficiency	>96.1% peak efficiency	>95% peak efficiency
Output	**Current per module**	**2.4 kW:** 50 A at 48 VDC (nominal input) 25 A maximum at 48 VDC (120 VAC)	**4.0 kW:** 83.3 A at 48 VDC (nominal input)
		3.0 kW: 62.5 A at 48 VDC (nominal) 32 A maximum at 48 VDC (120 VAC)	**4.6 kW:** 95.8 A at 48 VDC (nominal input)
	Rectifier module positions	**19-inch system:** Up to 8 rectifier modules	**19-inch system:** Up to 5 rectifier modules
		23-inch system: Up to 10 rectifier modules	**23-inch system:** Up to 6 rectifier modules

Mechanical			
		48 V-2.4/3.0 kW rectifier system	**48 V-4.0/4.6 kW rectifier system**
19-inch system	**Mounting**	Flush or center mount	
	Dimensions (H × W × D)	8.75 × 19 × 17.4 in. (222.1 × 482.6 × 442 mm)	12.25 × 19 × 16.6 in. (311 × 482.6 × 421.6 mm)
	Hot positions	21 load breakers **or** 16 load and 5 battery breakers	
		21 sets of 0.25-inch studs on 0.625-inch centers	
	Return positions	21 sets of 0.25-inch studs on 0.625-inch centers	
	Net weight (system)	45 lb (20.4 kg)	44 lb (20 kg)
23-inch system	**Mounting**	Flush or center mount	
	Dimensions (H × W × D)	8.75 × 23 × 17.4 in. (222.1 × 544.2 × 442 mm)	12.25 × 23 × 17.5 in. (311 × 544.2 × 444.5 mm)
	Hot positions	26 load breakers or 21 load and 5 battery breakers	
		26 sets of 0.25-inch studs on 0.625-inch centers	
	Return positions	26 sets of 0.25-inch studs on 0.625-inch centers	
	Net weight (system)	57 lb (25.8 kg)	50 lb (22.7 kg)
Net weight (rectifier module)		3.9 lb (1.76 kg) per module	8.6 lb (3.9 kg) per module
System access		Front-access after initial installation	
Controller		EnVision™ Elite Touch controller	
		Cordex® CXC HP system controller	
Environmental			
Operating temperature		–40 to 131°F (–40 to 55°C); –40 to 149°F (55 to 65°C) 4.6 kW derated at 104°F (40°C)	
Storage temperature		–40 to 185°F (–40 to 85°C)	
Relative humidity		0 to 95% non-condensing	
Elevation		Up to 6,600 ft (2,000 m)	Up to 6,600 ft (2,000 m)
		Up to 9,843 ft (3,000 m) with derated output	Up to 13,100 ft (4,000 m) with derated output
Cooling		Fan-cooled (front to rear)	
Heat dissipation		585 BTU/h (171 W) per module maximum	1348 BTU/h (395 W) per module maximum
Regulatory compliance			
Safety		CAN/CSA-C22.2 No. 60950-1-07	
		UL 60950-1	

3.3 Cordex® CXPS-E3 600 A Edge Power System

Table D: 48 V–3.0 kW Cordex® CXPS-E3 600 A edge power system			
Electrical			
System capacity (maximum)			
		System with battery LVD	**System without battery LVD**
Amperage		600 A total	600 A total
		550 A load	
		550 A battery	
		400 A maximum per tier	400 A maximum per tier
Input	**Operating voltage**	208 to 277 VAC (nominal)	
	Extended (high)	277 to 310 VAC (derated output power)	
	Extended (low)	90 to 187 VAC (derated output power)	
	Recommended AC breakers	Up to 4 × 40 A feeds and 2 × 20 A feeds	
	Efficiency	>96.1 % peak efficiency	
Output	**Current per module (nominal input)**	62.5 A at 48 VDC	
		55.5 A at 54 VDC	
	Rectifier module positions	Up to 10 rectifier modules	
Mechanical			
Mounting		Flush or center mount	
Dimensions (H × W × D)		10.1 × 23 × 19.5 in. (256.5 × 544.2 × 495.3 mm)	
Hot positions		26 load breakers 26 sets of 0.25-inch studs on 0.625-inch centers	
Return positions		26 sets of 0.25-inch studs on 0.625-inch centers	
Net weight (system)		60 lb (27.2 kg)	
Net weight (rectifier module)		3.88 lb (1.76 kg) per module	
System access		Front-access after initial installation	
Controller		EnVision™ Elite Touch controller	
		Cordex® CXC HP system controller	
Environmental			
Operating temperature		–40 to 131°F (–40 to 55°C); –40 to 149°F (55 to 65°C) derated output	
Storage temperature		–40 to 185°F (–40 to 85°C)	
Relative humidity		0 to 95% non-condensing	
Elevation		Up to 6,600 ft (2,000 m)	
Cooling		Fan-cooled (front to rear)	
Heat dissipation		585 BTU/h (171 W) per module maximum	
Regulatory compliance			
Safety		CAN/CSA-C22.2 No. 62368-1	
		UL 62368-1	

3.5 Cordex® CXPS-E3 600 A Edge Power System (Double Distribution)

Table F: 48 V–3.0 kW Cordex® CXPS-E3 600 A edge power system (double distribution)			
Electrical			
System capacity (maximum)			
		System with battery LVD	**System without battery LVD**
Amperage		600 A total	600 A total
		550 A load	
		550 A battery	
		400 A maximum per tier	400 A maximum per tier
Input	**Operating voltage**	208 to 277 VAC (nominal)	
	Extended (high)	277 to 310 VAC (derated output power)	
	Extended (low)	90 to 187 VAC (derated output power)	
	Recommended AC breakers	Up to 4 × 40 A feeds and 2 × 20 A feeds	
	Efficiency	>96.1 % peak efficiency	
Output	**Current per module (nominal input)**	62.5 A at 48 VDC	
		55.5 A at 54 VDC	
	Rectifier module positions	Up to 10 rectifier modules	
Mechanical			
Mounting		Flush or center mount	
Dimensions (H × W × D)		17.5 × 23 × 21 in. (444.5 × 584 × 533 mm)	
Hot positions		52 load breakers 52 sets of 0.25-inch studs on 0.625-inch centers	
Return positions		52 sets of 0.25-inch studs on 0.625-inch centers	
Net weight (system)		100 lb (45.4 kg)	
Net weight (rectifier module)		3.88 lb (1.76 kg) per module	
System access		Front-access after initial installation	
Controller		EnVision™ Elite Touch controller	
		Cordex® CXC HP system controller	
Environmental			
Operating temperature		–40 to 131°F (–40 to 55°C); –40 to 149°F (55 to 65°C) derated output	
Storage temperature		–40 to 185°F (–40 to 85°C)	
Relative humidity		0 to 95% non-condensing	
Elevation		Up to 6,600 ft (2,000 m)	
Cooling		Fan-cooled (front to rear)	
Heat dissipation		585 BTU/h (171 W) per module maximum	
Regulatory compliance			
Safety		CAN/CSA-C22.2 No. 62368-1	
		UL 62368-1	

3.4 Cordex® CXPS-E3 900 A Edge Power System


Table E: 48 V–2.4/3.0 kW Cordex® CXPS-E3 900 A edge power system			
Electrical			
		48V-2.4 kW rectifier system	**48V-3.0 kW rectifier system**
System capacity (maximum)			
Amperage		750 A load total	900 A load total
		450 A maximum per tier	450 A maximum per tier
Input	**Operating voltage**	208 to 277 VAC (nominal)	
	Extended (high)	277 to 310 VAC (derated output power)	
	Extended (low)	90 to 187 VAC (derated output power)	
	Recommended AC breakers	Up to 6 × 40 A feeds and 3 × 20 A feeds	
	Efficiency	>96.2% peak efficiency	>96.1% peak efficiency
Output	**Current**	900 A maximum	
	Current per module (nominal input)	50 A at 48 VDC	62.5 A at 48 VDC
		44.4 A at 54 VDC	55.5 A at 54 VDC
	Rectifier module positions	Up to 15 rectifier modules	
Mechanical			
Mounting		Flush or center mount	
Dimensions (H × W × D)		19.25 × 23 × 21 in. (489 × 685 × 533 mm)	
Rack space		11 RU	
Breaker positions		52 load breaker positions	
Hot (load) positions		52 sets of 0.25-inch studs on 0.625-inch centers	
Return positions		52 sets of 0.25-inch studs on 0.625-inch centers	
Net weight (system)		85 lb (38.7 kg)	
Net weight (rectifier module)		4.04 lb (1.83 kg) per module	
System access		Front-access after initial installation	
Controller		EnVision™ Elite Touch controller	
		Cordex® CXC HP system controller	
Environmental			
Operating temperature		–40 to 131°F (–40 to 55°C)	
Storage temperature		–40 to 185°F (–40 to 85°C)	
Relative humidity		0 to 95% non-condensing	
Elevation		Up to 9,186 ft (2,800 m)	
Cooling		Fan-cooled (front to rear)	
Heat dissipation		585 BTU/h (171 W) per module maximum	
Regulatory compliance			
Safety		CAN/CSA-C22.2 No. 62368-1	
		UL 62368-1	

4. Features

4.1 Seismic racks

The Cordex® CXPS-E3 edge power system can be installed in a variety of Alpha® 19-inch and 23-inch seismic racks. These racks have been Z4 rated and NEBS L3 certified. The racks vary in their Z4 seismic capabilities from 500 to 2,500 lb (227 to 1134 kg) and 3.5 to 9 feet in height (standard 7 foot racks are available as well). For more ordering information, refer to the Cordex® CXPS-E3 Edge Power System Ordering Guide (ID: 0470209-00).

19-inch or 23-inch seismic rack



4.2 Distribution panels

The power system has been designed with high density breaker or fuse count for use in 48 V applications and is rated for a total ampacity of 300, 400, 600, or 900 A. It is available either in a 19-inch or 23-inch configuration. All power systems include a back top cover for the protection of live customer connections.

4.2.1 300 and 400 A 19-inch distribution panels

Provides up to 21 breakers which can be configured as all load breakers 21 load breakers or a mix of load and battery breakers 16 load breakers and five battery breakers.

The all load breaker configurations have a shunt that monitors the total load current supplied by the rectifier modules to the load.

Both load and battery hot and return connections are made on ¼-inch studs on ⅝-inch centers using narrow tongue lugs. Adapter kits for landing larger cables are available when higher capacity two or three pole breakers are required.

4.2.2 300 and 400 A 23-inch distribution panels

This distribution assembly supports as many as 26 breakers, which can be configured as all load breakers (26 load breakers) or as a mix of load and battery breakers (21 load breakers and five battery breakers). The all-load-breaker configuration includes a shunt that monitors the total load current supplied by the rectifier modules. The load-and-battery configuration includes a shunt that monitors total battery charge and discharge current and incorporates a low-voltage battery disconnect (LVBD). Hot and return terminations are made on 0.25-inch studs set on 0.625-inch centers and accept narrow-tongue lugs. Adapter kits are available when larger cables are required for higher-capacity two-pole or three-pole breakers.

4.2.3 600 A 23-inch distribution panel (single distribution panel)

This distribution assembly supports as many as 26 load breakers with configurable battery-landing outputs. The all-load-breaker configuration includes a shunt that monitors the total load current supplied by the rectifier modules. The low-voltage battery-disconnect configuration includes a shunt that monitors total battery charge and discharge current and incorporates a low-voltage battery disconnect (LVBD). Hot and return terminations are made on 0.25-inch studs set on 0.625-inch centers and accept narrow-tongue lugs. Adapter kits are available when larger cables are required for higher-capacity two-pole or three-pole breakers. Two battery-landing busbar options are available for the 600 A 23-inch distribution panel: eight 2 AWG (35 mm²) battery landings, or two 350 kcmil (185 mm²) battery landings.

4.2.4 600 A 23-inch distribution panel (double distribution panel)

This distribution assembly supports as many as 52 load breakers with configurable battery-landing outputs. The all-load-breaker configuration includes a shunt that monitors the total load current supplied by the rectifier modules. The low-voltage battery-disconnect configuration includes a shunt that monitors total battery charge and discharge current and incorporates a low-voltage battery disconnect (LVBD). The 2 × LLVD configuration supports load shedding of non-critical loads.

Hot and return terminations are made on 0.25-inch studs set on 0.625-inch centers and accept narrow-tongue lugs. Adapter kits are available when larger cables are required for higher-capacity two-pole or three-pole breakers.

Busbar landings accommodate as many as two 4/0 AWG (120 mm²) cables and as many as four 2 AWG (35 mm²) cables.

4.2.5 900 A 23-inch distribution panel

This distribution assembly supports as many as 52 load breakers and provides extensive battery-landing capacity. It includes two 26-position distribution sections, each with independent load-current and breaker-status sensing. Total load current and overall breaker status are available through the controller interface, offering both flexibility and simplicity.

Hot and return terminations are made on 0.25-inch studs set on 0.625-inch centers and accept narrow-tongue lugs. Adapter kits are available when larger cables are required for higher-capacity two-pole or three-pole breakers.

Battery landings support wiring from the side, above, or below. Each polarity provides capacity for 10 0.25-inch studs on 0.625-inch spacing for 2 AWG (35 mm²) conductors, or two 0.375-inch studs on 1-inch spacing for 3/0 AWG (96 mm²) cables.

4.3 Control and monitoring methods

The power system front panel provides inputs and outputs for load and battery voltage, battery or load current, breaker alarms and disconnect control as well as monitoring. Additional I/O (expansion) is available for customer use. See the following table for the details.

Table G: Control and monitoring methods

Features	
Cordex® HP L-ADIO low voltage peripheral	
Dedicated I/O	• Bus voltage monitoring × 2 • Breaker alarm monitoring × 2 • Dry contact breaker alarm × 2 • Bus voltage sense × 2
Expansion I/O (customer use)	• Temperature sensor inputs × 4 • Form C relay outputs × 12 • Digital inputs × 6 • Voltage sense inputs × 2 • Current shunt inputs × 4
EnVision Elite Touch controller and Cordex® HP system controller	
	• Local connection to the Cordex® HP L-ADIO low voltage smart peripheral • Advanced user interface • Ethernet connection

4.3.1 Breaker labelling

For power systems with load only outputs, the numbering goes from left one to right; 21 for 19-inch power systems or 26 for 23-inch systems. For systems with batteries and loads, the load numbering goes from left one to center/right; 16 for 19-inch systems or 21 for 23-inch systems and the battery labelling goes from right one to left five.

There is a label on top of the front door which can be seen from the top when the door is closed, and from the front when the door is open. This label is larger and suitable for writing information about the breaker position.

There are two additional labels for breaker identification: a thin label above the breaker which can be read from the front (not writable), and one on the back/top near the return breakers which identify the positions of the return (not writable).

NOTICE

For the 600 and 900 A system, breaker labeling is not listed on the front door.

New

4.4 EnVision™ Elite Touch Controller

The EnVision™ Elite series controller is a next generation controller for smart networks. It is the cornerstone of the EnVision™ ecosystem which is built on the four pillars; control, sense, react, and explore; empowering your business to predict and prevent issues before they happen.

The EnVision™ Elite series controller offers cutting-edge performance, control, and monitoring while ensuring seamless integration with your current systems. Its backward compatibility with Alpha® power systems and the Cordex® HP controller form factor allows for easy upgrades with minimal disruption.

EnVision™ Elite series controllers are a direct replacement of the current Cordex® HP series controllers. They have enhanced security features, wireless connectivity, increased storage, and expanded capabilities to support a wider range of power equipment and peripherals.



Figure 11: EnVision™ Elite Touch controller ports and connections

1 **USB-A (USB 2.0) ports**
Dual ports on both the front and side of the controller for upgrades or file management via a standard USB drive.

2 **Ethernet ports**
Dual 10/100/1000 BASE-T Ethernet ports for connection on both the front and side of the controller for remote or local communication.

3 **Status LEDs**
Three front panel LEDs for alarms, progress, and status indication.

4 **2.4 GHz wireless antenna**
Configure a Wi-Fi access point on the controller and communicate with supported Bluetooth® devices.

5 **Touchscreen LCD panel**
Full color touchscreen LCD panel to access controls and menu items by using fingertip touch or a capacitive touch stylus.

6 **CAN ports**
CAN is used by the controller to discover, collect data from, control, and configure the power and I/O (ADIO) modules in the power system. The controller has two CAN buses, each of which can control up to 127 power and ADIO modules.

7 **Alarm connection**
Controller fail alarm relay contacts for extending various alarm and control signals. Each relay output can be wired for: normally open (NO), common (COM), and normally closed (NC) during an alarm or control condition.

8 **Main and redundant power connections**
Two 12 to 60 VDC input power connections. The EnVision™ Elite controller will operate when either power input is energized.

4.5 Front panel with controller and ADIO peripheral

The front panel includes the EnVision™ Elite Touch controller or Cordex® CXC HP system controller and a pre-wired Cordex® HP L-ADIO low voltage smart peripheral.

The Cordex® HP family of products provide centralized setup, control, and monitoring of power systems. This can range from simple monitoring and threshold alarms for temperature, voltage and current, to advanced battery charging and diagnostic features. The controller provides dual Ethernet ports allowing for simultaneous network, color touchscreen display panel, and local laptop access to the controller including both web and SNMP interfaces.

The controller supports two CAN ports to allow power or ADIO modules to be controlled and monitored. The controller uses external ADIO peripherals to monitor electrical signals (for example temperature and voltage) and generate electrical signals through relays.

The most commonly used ADIO peripheral is the Cordex® HP L-ADIO for low voltage systems which includes:

- 8 × digital inputs
- 4 × voltage sensors
- 4 × temperature sensors
- 4 × current sensors
- 12 × Form C relay outputs




Figure 12: Front panel with controller and Cordex® HP L-ADIO low voltage smart peripheral




Figure 13: Cordex® CXC HP system controller

The Cordex® CXC HP system controller has the following features:

Front touchscreen	Full-color touchscreen LCD used to access controls and menu items by touch or with a stylus.
Home button	Returns the user directly to the home screen from any menu.
Front panel reset	For emergency use only to restart the controller when the touchscreen or home button is unresponsive.
Front panel LEDs	Indicate alarms, progress, and system status.
Audio speaker	Built-in speaker that provides audible tones during active alarms; can be disabled if required.
Dual Ethernet ports	One RJ45 10/100 BASE-T Ethernet port on the front and one on the back for local or remote communication.
USB	One USB-A (USB 2.0) port on the front and one USB-A (USB 2.0) port on the back of the controller for upgrades or file management using a standard USB drive.
CAN	Two independent CAN-bus ports for communication with Cordex HP and AMPS products, supporting a larger number of devices.
Real-time clock	Field-replaceable lithium-battery-backed clock that provides timestamps for alarms and events.
System fail alarm/relay	Activates during a major internal failure; the controller attempts to reset during this condition.

4.5.1 Cordex® HP L-ADIO Low Voltage Smart Peripheral

Analog input channels

The peripheral includes analog input channels for monitoring voltage, current, and temperature.

Voltage inputs

The unit provides two voltage-input channels, V1 and V2, for monitoring discharge and charge voltages. V1 is assigned to Bus A Voltage and V2 to Bus B Voltage. Inputs V3 and V4 are not used by the power system and are available for customer-defined functions.

Temperature inputs


Up to four temperature sensors can be connected to monitor ambient conditions around the system. These analog values can be used to generate high-temperature or low-temperature alarms.

Digital input channels

The peripheral supports up to eight digital inputs. Inputs D1 and D2 are pre-wired for the Bus A Breaker Alarm and Bus B Breaker Alarm. Inputs D3 through D8 are available for customer use.

Alarm and control output relays

The peripheral includes 12 Form C digital alarm output relays for extending alarms and control signals to external equipment. Any internal alarm or control signal can be mapped to any relay, and multiple signals may be assigned to a single relay if required. Several relays are pre-configured for specific functions, including LVD control (K1, K5, or K6), minor alarm (K10), major alarm (K11), and critical alarm (K12).



1 K12 = Critical alarm

2 K11 = Major alarm

3 K10 = Minor alarm

4 V2 = Bus B voltage

5 V1 = Bus A voltage

6 PWR = Power input

7 K1 (if equipped) = 300A/400A LVD control

8 K5/K6 = 600A LVD control

9 D1 = Bus A alarm

10 D2 = Bus B alarm

11 CAN IN port

12 CAN out port

Figure 14: Cordex® HP L-ADIO low voltage smart peripheral

Network connection and remote communications

The system can be set up, monitored, and tested via an Ethernet IEEE 10/100/1000 BASE-T serial data connection. The communication protocol supports a web interface. A CAN bus is used to transmit all alarm and control functions between the controller and rectifier modules.

Refer to the software manual for operation of the controller.

Front panel wiring notes

The terminal blocks on the indicator boards are suitable for 26 to 16 AWG (0.14 to 1.5 mm²) wire. As both signals are low current, it is recommend to use thinner wire where possible to make routing easier and to minimize space consumed by in the system. This is especially important with the Cordex® HP L-ADIO low voltage smart peripheral if many of the expansion I/O capabilities are to be used.

Added wiring should be routed along the same path as the bus connection cable and then extend through the back of the unit. Take care to restrain the wiring sufficiently while providing enough slack so as not to interfere with operation of the door. Use the cable tie locations on the Cordex® HP L-ADIO low voltage smart peripheral to restrain the cables within the front panel, and use the lance features on the chassis side panels to guide the cabling to the back of the unit.

4.6 Cordex® HP 2.4 kW Rectifier Module

4.6.1 Features

This rectifier module delivers 50 A of high-performance output for 48 VDC telecom applications in a compact, high-power-density design (28 W/in³), allowing more space for revenue-generating equipment. Its high-efficiency architecture reduces operating expense and lowers the overall carbon footprint. The module supports a wide AC-input operating range for global deployment and is available in multiple configurations providing up to 250 A or 12 kW. It is engineered for installation in non-controlled environments, with an extended operating-temperature range suitable for the harshest outdoor conditions.

4.7 Cordex® HP 3.0 kW Rectifier Module

4.7.1 Features

This rectifier module delivers 62.5 A of high-performance output for 48 VDC telecom applications in a compact, high-power-density design (35 W/in³), maximizing available space for revenue-generating equipment. Its high-efficiency architecture reduces operating expense and lowers the overall carbon footprint. The module supports a wide AC-input operating range for global deployment and is available in multiple configurations providing up to 312.5 A or 15 kW. It is engineered for installation in non-controlled environments, with an extended operating-temperature range suitable for the harshest outdoor conditions.

4.8 Cordex® HP 4.0 kW Rectifier Module

4.8.1 Features

This rectifier module delivers 83.3 A of high-performance output for 48 VDC telecom applications in a compact 4RU form factor, providing up to 24 kW per 23-inch shelf. Its high-efficiency design reduces operating expense and lowers the overall carbon footprint, while its high-power-density architecture maximizes available space for revenue-generating equipment. The module supports power-limiting operation and a wide AC-input range for global deployment. It is engineered for installation in non-controlled environments, with an extended operating-temperature range suitable for the harshest outdoor conditions.

4.9 Cordex® HP 4.6 kW Rectifier Module

4.9.1 Features

This rectifier module delivers 95.8 A of high-performance output for 48 VDC telecom applications in a compact 4RU form factor, providing up to 27.6 kW per 23-inch shelf. Its high-efficiency architecture reduces operating expense and lowers the overall carbon footprint, while its high-power-density design maximizes available space for revenue-generating equipment. The module supports power-limiting operation and a wide AC-input range for global deployment. It is engineered for installation in non-controlled environments, with an extended operating-temperature range suitable for the harshest outdoor conditions

4.10 Rectifier module front panel LEDs

Each rectifier module has three LEDs for status indication. See the Troubleshooting section for LED states and meanings.

4.11 300, 400, and 600 A LVD override

For systems with LVD, an override interface is provided, see Figure 15. This interface board includes three LEDs to provide visual status indication, and two customer connections for remote control and monitoring:

NOTICE

The 600 A double distribution system supports this feature.




Figure 15: LVD override




Figure 16: LVD override interface

4.9.2 LVD override board LEDs

Each LVD override board has three LEDs for status indication. See the Troubleshooting section for LED states and meanings.

4.9.3 LVD override board connections

Connections

- **OVERRIDE:** 48 V/5 mA signal, active when override switch is in override position.
- **COIL CTRL:** Control input for LVBD coil, can be configured for remote control or remote disable. When configured for remote control (default), a dry contact connected to the coil control input can turn on the LVBD independently of the LVD or the automatic control.
- When configured for remote disable, the coil control input must be shorted by a dry contact for either the automatic control or the LVD override to operate.

The LVD override interface is configured for remote control by default for most systems.

To change configuration:

This operation must be done with AC and DC power disconnected, ideally prior to commissioning the system.

1. Remove the interface from the power system by removing the two screws from the front:
2. Lower the board, and pull it forward through the opening.
3. Flip the board over, and observe the jumper on the bottom of the board.
4. Move the jumper to the desired position:
5. CTRL (normally open; NO) position: The COIL CTRL is configured for remote control.
6. ENBL (normally closed; NC), COIL CTRL position: For remote enable.
7. After the jumper is set check all cable connections (in case they were pulled loose when the board was removed).
8. Reinstall the board and labels using the original screws.




Figure 17: LVD override connections

4.12 600 A LVD override

4.12.1 Introduction

Contactors are mechanical switches, which connect and disconnect high current power sources and electrical load, for example between rectifier modules and batteries or loads in a power system. The 600 A edge power system takes advantage of the higher efficiency and smaller form factor of a latching contactor, along with heavier buswork, to enable a much higher current rating than 400 A edge power systems in the same physical volume. For example, when combined with 3.0 kW rectifier modules, it has a rating of 625 A compared to 450 A for 400 A edge power systems with 2.4 kW rectifier modules. To safely and reliably control the latching contactor, 600 A edge power systems have a different LVD interface board than 400 A edge power systems. While 400 A edge power systems has an LVD override board, which enabled service to force the LVD on even if the controller was removed, 600 A edge power systems have an LVD control interface which buffers the ADIO peripheral control signals for the higher coil current and enables manual operation.

Traditionally the telecom industry has used non-latching contactors which have a simple operation: when power is provided to the contactor it closes and maintains closure (connecting two points electrically); if power is removed the contactor automatically opens. The advantage of these contactors is that if power is lost to the contactor they simply open, so called fail-safe operation, but the disadvantages are continuous heat losses in driving the coil closed and higher losses in the electrical contacts.

A latching contactor has a strong permanent magnet capable of holding the contacts closed and only a short pulse of current is needed to close it initially. Because coil operation is only temporary a much higher current can be allowed without concern of overheating, and this allows the closing force to be higher. The result is lower electrical losses in both the actuating coil and the load connections, overall providing a more compact and efficient design. The added complexity makes these contactors a little more expensive, but the more significant difference is that if power fails they do not automatically open. Depending on the application this might be viewed as an advantage or disadvantage; the inherent fail-safe operation is lost, but it is also less likely to unexpectedly drop a load by opening due to controller failure.

4.12.2 Normal operation

Standard function

In a 600 A edge power system, the latching contactor is used as a low voltage battery disconnect (LVBD) between a bulk feed input and the main bus where the load breakers connect. During normal operation the LVBD is closed, the battery bank is connected to the main bus, and the batteries are charging. The user will have to set a minimum voltage threshold, below which the batteries might be damaged if discharged. The user will also have to set a reconnection voltage above which the batteries should reconnect to the main bus. As per standard practice the reconnect voltage is above the battery open circuit voltage so it will not reconnect until AC power returns. From this state the controller will use two control relays on the ADIO peripheral to control the contactor state as described.

Upon AC power failure, the batteries discharge to support the critical load. If the main voltage falls below the threshold where the batteries may be permanently damaged, the controller opens the latching LVBD by energizing a relay on the ADIO peripheral, which is connected to the latching interface board. When the LVBD opens the batteries disconnect, and within a few seconds the controller loses power and turns off and the control relay on the ADIO peripheral is disabled.

Upon return of AC power if the batteries are disconnected, the rectifier modules turn on and provide power to the load. Once the main bus voltage exceeds the reconnect threshold, the controller closes the LVBD by energizing a relay on the ADIO peripheral (different than the one that is used to open the contactor). This connects the batteries to the main bus and returns the system to a normal operating state.

Fault recovery and alarms

The controller monitors the state of the LVBD through a digital input on the ADIO peripheral board. If the controller detects that the LVBD state is not as expected (closed when expected to be open or open when expected to be closed), it attempts to correct this by energizing the appropriate control relays. For example, if a service person opens the contactor using the manual controls (refer to service operation) then the controller attempts to reclose it within two to three seconds.

In the case where the state remains incorrect the controller attempts to correct it up to three consecutive times. After those three attempts it generates a user alarm and waits 15 minutes before trying again. This overall cycle of three attempts followed by a 15 minute pause continues until the contactor changes state, is disabled, or serviced.

Contactor state

The contactor state is monitored through the ADIO peripheral on **Digital Input D3**. This can be seen on the controller display or through the web interface.

Battery not present

The LVD control interface uses power from the battery side to drive the contactor coil. Therefore if a battery is not connected the contactor does not operate. Operation without a battery is described in the service section.

4.12.3 Service operation

The LVD interface board provides two manual control buttons for service use: close and open. To operate the contactor a pulse of current is sent to the contactor and for each of the operations there is a yellow LED and a push button switch. Each yellow LED turns on when and if the pulse generator is charged for the respective operation, that is, when it is ready.

Close		Open		Control power
RDY (yellow LED)	CTRL (switch)	RDY (yellow LED)	CTRL (switch)	Green LED

Note that the pulse generator charges through the normally closed (NC) terminal of the associated relay on the ADIO peripheral. Therefore the associated control wiring must be plugged into the ADIO peripheral for the manual operation to work, specifically K6 for close and K5 for open. This feature can be used to disable the controller so that it cannot override manual operation; the specific options and operations are as follows:

Operation

1. Disable the LVD. From the controller, go to **Systems > DC System > Inventory > Disconnects**.
2. Push the button to put the LVD in the desired state.
3. Unplug K5/K6 (optional).
4. Perform maintenance work.
5. Plug in K5/K6 if unplugged in step 3.
6. Push the button to put the LVD in the desired state (optional).
7. Enable the LVD. From the controller, go to **Systems > DC System > Inventory > Disconnects**.

Operation	K5	K6	Action
Close contactor but allow the controller to re-open.	Any	Plugged in	Select **Closed**
Open contactor but allow the controller to re-close.	Plugged in	Any	Select **Open**
Close contactor and prevent the controller from re-opening.	Unplugged	Plugged in	Select **Closed**
Open contactor and prevent the controller from re-opening.	Plugged in	Unplugged	Select **Open**

NOTICE

If the controller is non-functioning, this table can be used for operation of the LVD.

Control power LED

The latching interface board also performs the ancillary function of combining the battery and rectifier module outputs for the controller and ADIO peripheral control devices so they are powered when either source is present. The control power LED simply provides the status that either one of these sources is present.

Latching interface background

The LVD control interface translates the ADIO peripheral control relay state change into a fixed duration high current pulse to the contactor, thus preventing the contactor coil from being continuously powered in case of operator or controller error. It does this by charging a capacitor in the pulse generator when a control relay is off, and then discharging it when the control relay is on. Therefore, it is necessary to have the control relay off for a short time period (<1 second) between actuation attempts. This recharging is done through the normally closed (NC) contacts of the control relay on the ADIO peripheral.

Troubleshooting

Symptom	Possible cause
Manual operation does not work	Check if related LED is illuminated, if not check the ADIO peripheral connection.
Contactor closes after manual opening	Check controller function, is it reconnecting due to high battery voltage? If so unplug K6.
Contactor opens after manual closing	Check controller function, is it disconnecting due to low battery voltage? If so unplug K5.
Contactor won't operate and the green LED on LVD control interface board is not illuminated	Check if battery or rectifier module output is live.
Contactor won't operate but the green LED on LVD control interface board is illuminated	Check if the battery is disconnected. (If the rectifier module output is live the load bus will power the green LED.)

4.13 Integrated battery trays

Edge power systems are designed to integrate battery trays below the power system. These battery trays can accept standard 12 V monoblocks ranging in height from 6RU to 8RU. The battery trays are factory installed and pre-wired for ease of installation. They can be configured with or without battery breakers as overcurrent protection devices (OCPD). The battery breakers are installed within a breaker housing on the side of each battery tray. The breaker sizes and its associated cabling can range from 100 to 250 A.




Figure 18: Integrated battery tray

When battery trays are ordered for systems without a low voltage battery disconnect (LVBD), the battery cable landing busbar kit will need to be ordered. This kit provides a secure location to terminate each individual battery tray cable to the main power system bus enabling a neat and clean install. In addition, this kit provides sufficient access to customers in the event that a battery tray and its associated cabling needs to be added in the field on a live plant.

4.14 Battery landing busbar kit

4.14.1 300 A power system battery landing busbar kit

Cordex® CXPS-E3 300 A edge power systems can be purchased with an optional battery landing busbar kit (PN: 0250030-550) which provides landing locations for three pairs of back-to-back cable lugs. This kit is customer installed at time of system installation.

4.14.2 400 A power system battery landing busbar kit

Cordex® CXPS-E3 400 A edge power systems can be purchased with an optional battery landing busbar kit (PN: 0250030-550) which provides landing locations for three pairs of back-to-back cable lugs. This kit is customer installed at time of system installation.

4.14.3 600 A power system battery landing busbar kit (single distribution)

Cordex® CXPS-E3 600 A edge power systems by default come with an extended battery landing busbar kit, either PN: 0250030-531 or PN: 0250030-532, which provides either eight 2 AWG (35 mm²) landing points or two 350 kcmil (185 mm²) landing points. These kits are interchangeable and can be purchased separately and installed by the customer during system installation.

4.14.4 900 A power system battery landing busbar kit

Cordex® CXPS-E3 900 A edge power systems by default come with battery landings installed. It provides both four 4/0 AWG (120 mm²) landing locations and six 2 AWG (35 mm²) landing points all through back-to-back mounted connection pairs.




Figure 19: Battery landing busbar kit

5. Inspection

5.1 Packaging materials

Alpha Technologies Ltd. is committed to providing products and services that meet our customers' needs and expectations in a sustainable manner, while complying with all relevant regulatory requirements. As such Alpha® strives to follow our quality and environmental objectives from product supply and development through to the packaging for our products.

Rectifier modules and batteries are shipped on individual pallets and are packaged according to the manufacturer's guidelines.

Almost all Alpha® packaging material is from sustainable resources and or is recyclable.

5.2 Returns for service

NOTICE

Alpha Technologies Ltd. is not responsible for damage caused by improper packaging of returned products.

Save the original shipping container. If the product needs to be returned for service, it should be packaged in its original shipping container. If the original container is unavailable, make sure that the product is packed with at least three inches of shock-absorbing material to prevent shipping damage.

5.3 Check for damage

Before unpacking the product, note any damage to the shipping container. Unpack the product and inspect the exterior for damage. If any damage is observed, contact the carrier immediately. Continue the inspection for any internal damage. In the unlikely event of internal damage, inform the carrier and contact Alpha Technologies Ltd. for advice on the impact of any damage.

5.4 General receipt of shipment

The inventory included with your shipment depends on the options you have ordered. The options are clearly marked on the shipping container labels and bill of materials.

5.5 Miscellaneous small parts

Review the packing slip and bill of materials to determine the part number of the configuration kits included with your system. Review the bill of materials to verify that all the small parts are included. Contact us if you have any questions before you proceed.

6. Installation

Only qualified personnel should install and connect the power components within the Cordex® power system. For the battery installation, refer primarily to the manufacturer's documentation.

Frequent reference is made to drawings located at the end of this document.

6.1 Safety precautions

Refer to the Safety section near the beginning of this document.

6.2 Tools required

Various insulated tools are essential for the installation. Use this list as a guide:

- Battery lifting apparatus if required
- Electric drill with hammer action, ½-inch capacity
- Various crimping tools and dies to match lugs used in installation
- Load bank of sufficient capacity to load largest rectifier module to its current limit
- Digital voltmeter equipped with test leads
- Cable cutters
- Torque wrench: ¼-inch drive, 0 to 150 in-lb (0 to 17 N·m)
- Torque wrench: ⅜-inch drive, 0 to 100 ft-lb (0 to 135 N·m)
- Insulating canvases as required
- Various insulated hand tools including:
  - Combination wrenches
  - Ratchet and socket set
  - Various screwdrivers
  - Electricians knife
- Battery safety spill kit required for wet cells only
- Cutters and wire strippers 14 to 22 AWG (2.5 to 0.34 mm²)

6.3 Installation of external batteries

This information is provided as a guideline and is not meant to imply that batteries are part of this power system.

Batteries should be located in a temperature-controlled environment, regulated to approximately 77°F (25°C). Significantly lower temperatures reduce performance and higher temperatures decrease life expectancy.

Provide adequate ventilation. VRLA batteries, though not requiring the special ventilation requirements of a flooded battery, should not be installed in an airtight enclosure. Hydrogen gas can be emitted from a failed battery.

If applicable, clean the cells before assembly according to the battery manufacturer's recommendations. First neutralize any acid with a baking soda and water solution; then wipe the cells with a soft cotton cloth dampened with clean water and wipe dry.



WARNING

Follow the battery manufacturer's safety recommendations when working around battery systems and review the safety instructions provided in this document.

6.3.1 Installing batteries

1. Verify that all battery breakers, DC circuit breakers, and fuses on the distribution panels are in the off position or removed.
2. Apply a corrosion-inhibiting compound, such as Sanchem NO-OX-ID® A-SPECIAL electrical grease, to all battery-terminal connection points.
3. If required, assemble the battery rack and install the cells or mono-blocks according to the installation instructions supplied with the batteries.
4. Ensure that the battery output cabling can reach the positive [+] and negative [–] terminals of the series battery string, and confirm that the batteries are oriented to allow easy installation of the inter-unit series connectors.
5. Remove any electrical grease from battery terminals.
6. Burnish the terminal posts with a non-metallic brush, polishing pad, or 3M Scotch-Brite® scouring pad.
7. Apply a light coating of electrical grease to the terminal posts.
8. If lead-plated inter-unit connectors are used, burnish them and apply electrical grease as above. Install the inter-unit connectors.
9. After all battery connections are completed, torque the connections according to the battery specifications, typically 100 in-lb (11.4 N·m).

Refer to the system startup procedure before connecting the batteries online.

6.4 Battery maintenance report

After assembly, number the batteries and take as received readings, including specific gravity, cell voltage, and temperature. Designate one cell as the pilot cell. This is usually the cell with either the lowest specific gravity or voltage. Refer to the manufacturer's documentation for guidelines. See the following table for typical maintenance report:

Company:	Date:	
Address:		
Battery location and number:		
Number of cells:	Type:	Date new:
Date installed:	Float voltage:	Ambient temperature:

Table I: Typical VRLA battery maintenance report

Cell number	Serial number	Voltage	Specific	Ohms	Mhos	Observations

Remarks and recommendations:
Readings taken by:

6.5 Power system assembly and mounting

The power system must be mounted in a clean and dry environment. Sufficient free space must be provided at the front and back of the power system. This is to meet the cooling requirements of the rectifier modules and to allow easy access to the power system components.

NOTICE

The power system requires at least 2RU (3.5 inches) of space above the distribution for tooling access to the load breaker ground connections. Ensure that at least 2RU of space is open in the relay rack above the power system distribution. Some of this space may be consumed by the clear plastic cover of the power system in higher ambient temperature environments.

6.5.1 Floor mounted systems

Floor mounting

Secure the system to a concrete floor using heavy-duty anchors (0.50-inch × 2.50-inch). For wooden floors, use heavy-duty lag screws (0.625-inch × 2.50-inch). Install appropriately sized flat washers under each fastener.

If required, install isolation kits to electrically isolate the system from the floor.

Overhead support

Secure the relay rack to the overhead cable tray. Mechanical details for overhead support are not supplied by Alpha.

System weight

The weight of the systems listed are approximate and exclude rectifier modules:

System	Weight
Cordex® CXPS-E3 300 A edge power system 19-inch with 1 × 2.4/3.0 kW rectifier shelf	35.1 lb (15.9 kg)
Cordex® CXPS-E3 300 A edge power system 23-inch with 1 × 2.4/3.0 kW rectifier shelf	44.4 lb (20.1 kg)
Cordex® CXPS-E3 400 A edge power system 19-inch with 2 × 2.4/3.0 kW rectifier shelves	40 lb (18.2 kg)
Cordex® CXPS-E3 400 A edge power system 19-inch with 1 × 4.0/4.6 kW rectifier shelf	56 lb (25.5 kg)
Cordex® CXPS-E3 400 A edge power system 23-inch with 2 × 2.4/3.0 kW rectifier shelves	58 lb (26.4 kg)
Cordex® CXPS-E3 400 A edge power system 23-inch with 2 × 4.0/4.6 kW rectifier shelves	60 lb (27.2 kg)
Cordex® CXPS-E3 600 A edge power system 23-inch with 2 × 2.4/3.0 kW rectifier shelves (single distribution panel)	60 lb (27.2 kg)
Cordex® CXPS-E3 600 A edge power system 23-inch with 2 × 2.4/3.0 kW rectifier shelves (double distribution panel)	100 lb (45.4 kg
Cordex® CXPS-E3 900 A edge power system 23-inch with 3 × 2.4/3.0 kW rectifier shelves	100 lb (45.4 kg)

Refer to the drawings at the end of this document for system dimensions.

Dimensions in Figure 20 and Figure 21 are in inches.




Figure 20: Rack mounting details (top view), welded rack




Figure 21: Rack mounting details (top view), bolted rack

6.5.2 Rack mounted systems

Attach the power system to the customer-provided relay rack using mounting screws and star washers to ensure an electrical bond between system chassis and relay rack.

19- and 23-inch power systems may be either flush or center mounted in the relay rack.

6.5.3 Systems mounted in outdoor enclosures operated above 104°F (40°C)

Attach the power system to the customer provided enclosure using mounting screws and star washers to ensure an electrical bond between system chassis and relay rack. 19- and 23-inch power systems may be either flush or center mounted in the enclosure.

If the system will be operated in ambient temperatures above 104°F (40°C), these installation steps must also be followed:

1. The clear polycarbonate top cover must be removed, if applicable.
2. The enclosure design must prevent the operator from touching the output busbars/lug connections.
3. The battery breakers used must be rated 100 A or lower, if applicable.
4. Air circulation within the enclosure must be sufficient to maintain the breaker bullets below 221°F (105°C) in all operation conditions.

NOTICE

With step 4, the air circulation required is considerably less than what is normally designed into an outdoor enclosure, therefore this should be met by standard designs. However, as cooling performance is very specific to the mechanical implementation, it is recommended to test for compliance under maximum load conditions (using battery discharge test).

6.6 Breaker installation

1. Ensure mid-trip breakers are used for load and series-trip breakers are used for battery connections.
2. Turn the breaker OFF.
3. Orient the breaker so that the actuator is down with the breaker in the off position.
4. Align the breaker terminals with the correct holes.
5. Carefully push the breaker into position.
6. Ensure that the breaker is fully inserted so that the flat face of the hexagonal nut is against the mounting surface.




Figure 22: Breaker installation

6.6.1 Breaker removal

1. Turn breaker off.
2. Carefully pull the breaker out of position.

7. Wiring

This chapter provides cabling details and notes on cable sizing for DC applications with respect to the product.



WARNING

Ensure that the power is switched off by switching off rectifier modules and removing battery line fuses, turn off battery breakers before attempting work on the wiring. Use a voltmeter to verify the absence of a voltage. Clearly mark the correct polarity of the battery leads before starting work on DC connections.

7.1 Installation notes



ATTENTION

Cordex® CXPS-E3 edge power systems must be installed above a non-combustible surface.

Refer to the Installation section for safety precautions and tools required.

7.1.1 Calculating input and output wire size requirements

Although DC power wiring and cabling in telecommunication applications tend to exceed electrical code requirements, mostly due to the voltage drop requirements, all applicable electrical codes take precedence over the guidelines and procedures in the present chapter, wherever applicable.

Wire size is calculated by first determining the appropriate maximum voltage drop requirement. Use the following formula to calculate the circular mil area (CMA) wire size requirement. Determine the size and number of conductors required to satisfy the CMA requirement.

$$\mathbf{CMA = (A \times LF \times K) / AVD}$$

A = Ultimate drain in amps.

LF = Conductor loop feet.

K = 11.1 constant factor for commercial (TW type) copper wire.

AVD = Allowable voltage drop.

Check again that the ampacity rating of the cable meets the requirement for the installation application. Consult local electrical codes (for example, National Electrical Code® and Canadian Electrical Code) for guidelines. If required, increase the size of the cable to meet the code.

Refer to Table I for cable size equivalents.

Table J: Cable size equivalents (Imperial to Metric)

Imperial	Circular mils	Square millimeters	Equivalent metric cable
20 AWG	1020	0.519	1
18 AWG	1624	0.8232	1
16 AWG	2583	1.309	1.5
14 AWG	4107	2.081	2.5
12 AWG	6530	3.309	4
10 AWG	10380	5.261	6
8 AWG	16510	8.368	10
6 AWG	26250	13.30	16
4 AWG	41740	21.15	25
2 AWG	66370	33.63	35
0 AWG (or 1/0)	105600	53.48	50 or 70

Table J: Cable size equivalents (Imperial to Metric)			
Imperial	**Circular mils**	**Square millimeters**	**Equivalent metric cable**
00 AWG (or 2/0)	133100	67.42	70
0000 AWG (or 4/0)	211600	107.2	120
313 kcmil	313600	159	150 or 185
350 kcmil	350000	177.36	185
373 kcmil	373700	189	185 or 240
500 kcmil	500000	253.36	300
535 kcmil	535300	271	300
750 kcmil	750000	380.00	400
777 kcmil	777700	394	400

7.1.2 Required torque values

Table J lists the recommended torque values for connection to the power system with the following hardware:

- Clear hole connections (nut and bolt)
- PEM studs
- PEM threaded inserts
- Thread formed connections (in copper busbar)

SAE Grade 5 rated hardware is required for these torque values. Use factory provided hardware or zinc-chromate. Stainless or other metals have a different torque specification.

Table K: Recommended torque values	
Size	**Torque value**
¼-inch	8.8 ft-lb (11.93 N·m)
⅜-inch	32.5 ft-lb (44.06 N·m)
½-inch	73 ft-lb (98.97 N·m)

7.2 Grounding

Connect the isolated power system battery return bus (BRB) to the building master ground bus (MGB), or floor ground bus (FGB) in a larger building. This acts as a system reference and as a low impedance path to the ground for surges, transients and noise. The MGB or FGB must have a direct low impedance path to the building grounding system.

The cable from the power system to the MGB or FGB must be sized to provide sufficient ampacity to clear the largest fuse or breaker on the power system, excluding the battery protection fuse or circuit breaker. This is the minimum requirement. Other factors including length of cable and special grounding requirements of the load must also be factored in. The insulated cable must be equipped with two-hole crimp type lugs and must not have any tight bends or kinks.

Table L: Typical ground reference conductor selection	
Power system ampacity	**Recommended ground reference conductor size**
<30 A	10 AWG (6 mm²)
30 A to 100 A	6 to 2 AWG (16 to 35 mm²)
100 A to 400 A	0000 AWG (107 mm²)
400 A to 800 A	350 kcmil (185 mm²)
>800 A	750 kcmil (400 mm²)

The power system frame must also be connected to the MGB or FGB. This is done for personnel safety and to meet many telecom grounding requirements. Each bay must have its own frame or site ground connection. Refer also to the customer connections drawing at the end of this document.

7.2.1 Frame ground

There are several options for connecting a frame ground to the power system (select just one option):

- The options highlighted on either side of the power system distribution.
- As highlighted in the Cordex® HP 2.4/3.0 kW Rectifier User Guide (ID: 0100037-J0), a back connection on the side of the AC termination box.
- If the frame that the power system is installed into is grounded, then it can also be grounded as a final option through the mounting ears on the side of the power system through the frame.

Connection to power system directly

Connect a cable (matched to maximum size breaker, usually 2 AWG (35 mm²) or less between one of the side panels of the power system to the master ground bus (MGB) or floor ground bus (FGB). This connection can be made using a 0.25-inch × 0.625-inch lug and two 0.25-inch × 20 bolts into the PEM nuts indicated in the following drawing.




Figure 23: Connecting the frame ground to the power system

Connection to overhead trays

Connect the power system to the frame using rails using 12-24 self-tapping screws. Ensure paint is removed to ensure a good electrical connection between power system and frame.

Connect a cable to the frame in which the power system is installed. The rack upper crossbar (Figure 24) has five 0.625-inch diameter holes to accommodate threaded rod attachment to the overhead trays. Connect the frame ground 0.375-inch on 1.00-inch centers and 0.25-inch on 0.625-inch centers. Remove paint in lug contact area to ensure a good electrical connection.




Figure 24: Connecting the frame ground to overhead trays



7.2.2 Reference ground

The reference ground should be connected between the building master ground bus (MGB) or floor ground bus (FGB) and the power system internal battery return bus (BRB) in **only one** location.

ATTENTION

If the MGB or FGB is connected to the power system BRB in more than one location then load current will circulate through the reference ground bond, creating and unsafe condition known as ground loop.

Exact connection should be determined by the site engineer, but in general the recommended connection locations are:

Order of precedence	System characteristic	Connection point
1	2V battery stacks	Battery termination bar.
2	Connected to larger power system	Power system internal battery return bus.
3	Battery landing busbar	If this option is included (extends out through back cover). 
4	Return bar location	

7.3 AC wiring

To ease future access issues, connect the AC circuits to all rectifier shelves at the time of initial installation.

NOTICE

Verify no rectifier modules are installed in the rectifier shelves at this time.

7.3.1 AC feeder protection and sizing

To maximize system reliability, each feed should have a dedicated protection feeder breaker located at the AC distribution panel. The feeder breaker can also act as the disconnect device for the connected modules.

ATTENTION

To minimize EMI disturbances, route the AC input wires in flexible or rigid conduit and located as far away as possible from the DC power wires.

7.3.2 AC wiring for Cordex® HP 2.4/3.0 kW Rectifier Shelves

Cordex® HP 2.4/3.0 kW rectifier shelves used within power systems are 19-inches or 23-inches in width. The individual rectifier shelves are wired to the customer provided AC termination panel. The AC input is routed through a ¾ inch trade size knockout on the side of the shelf for a direct connection. The AC wiring size can vary based on local electrical codes.

The recommended AC breaker and wire gauge sizes are as follows:

Rectifier shelf	Recommended AC breaker size	Recommended AC wire size
Single phase, 208 to 277 VAC	23-inch breaker = 2 × 40 amp and 1 × 20 A AC breakers 19-inch breakers = 4 × 20 A AC breakers	8 AWG (10 mm²) for 40 A breakers 12 AWG (4 mm²) for 20 A breakers

Refer to the Specifications section for further details.

CAUTION

Use care when removing or replacing the covers for the AC input connections. Never assume that an electrical connection or conductor is not energized.

1. Ensure that all modules are removed from the shelf.
2. At the back of the shelf, remove screw and flip the cover down (two places) to access the AC input terminal blocks: each terminal pair corresponds to either two rectifier modules or one rectifier module as shown in Figure 25.
3. The wire way is designed for two customer-supplied, ¾ inch conduit fittings for the AC supplies located one on each side of the shelf. Attach the conduit retainers to the wire way holes and route the AC cables through them.
4. Secure the wires to the AC input and AC ground terminals. Refer to the customer connection drawing at the end of the document.
5. Tighten the cable connector to the AC cable (conduit similar).
6. Replace back covers once all connections have been completed.




Figure 25: AC input and ground for 23-inch shelf

7.4.2 AC wiring for Cordex® HP 4.0/4.6 kW Rectifier Shelves

Cordex® HP 4.0/4.6 kW rectifier shelves used within power systems are 19-inches or 23-inches in width. The individual rectifier shelves are wired to the customer provided AC termination panel. The AC input is routed through a 1.00-inch trade size knockout on the side of the shelf for a direct connection. The AC wiring size depends upon the rectifier shelf voltage configuration and the local electrical code.

The recommended AC breaker and wire gauge sizes are as follows:

Rectifier shelf	Recommended AC breaker size	Recommended AC wire size
Single phase, 208 to 277 VAC	6 × 30 A AC breakers	10 AWG (6 mm²)
Three phase, 208 VAC (without neutral)	2 × 50 A AC breakers	6 AWG (16 mm²)
Three phase, 277/480 VAC (with neutral)	2 × 30 A AC breakers	10 AWG (6 mm²)

7.4.3 AC wiring for Cordex® HP 4.0 kW Rectifier Shelves

Figure 26 shows the AC connections for one of the rectifier shelves. For other AC connection options (for example, single phase), refer to the rectifier shelf document that ships with your system.

Terminate flex conduit at rectifier shelves—one connection each side.




Figure 26: Shelf AC connection (three-phase, three-wire shown with back cover removed)

7.4 DC wiring

CAUTION

Leave cables or busbars disconnected at the battery and verify the output polarity using a voltmeter. Make battery connections only after all other wiring is completed.

DC output wire must be UL approved XHHW or RHH/RHW (for Canadian users, RW90 Type). Control and sense wires must be UL approved Style 1015 (for Canadian users, TEW type).

The common output leg of the rectifier system must be connected to ground, typically at the battery return bus.

7.4.1 External battery bay output connections

Battery cables must be sized for a 0.25 V drop from the battery to the power system at full load including anticipated growth. The cables must also meet ampacity requirements. Cables terminating directly on the battery posts or connection details must be secured so that there is no stress on the battery posts. Lead plated lugs and lead plated or stainless steel hardware must be used on all terminations at vented batteries to reduce corrosion.

1. Prepare, route, and connect cables from the power system to the battery termination details—connections are available for both hot and return.
2. Burnish the terminating points and apply a corrosion-inhibiting agent, such as Sanchem Inc. NO-OX-ID® A-SPECIAL electrical grease, to all battery terminal connections.
3. Do not complete the final live connections to the battery. Leave open and insulate the final connections or remove the battery fuses. Switch off the battery contacts if used.

Refer to the system startup procedure before connecting the batteries online.

7.5 Distribution cabling

7.5.1 Load planning and breaker (fuse) spacing



CAUTION

For applications when the power system is subjected to ambient temperatures above 131°F (55°C) it must be installed inside equipment such that unintentional contact with the area of the side panels between the mid-mount bracket and the back of the unit is unlikely. For clarity, this is the area marked with a Caution—Hot label.



NOTICE

Connect breaker returns before hot connections.

Because breakers and fuses generate most of the heat in a system, care must be taken in the layout of high current breakers and fuses. Specific guidelines are as follows:

For Cordex® CXPS-E3 300 A Edge Power Systems

1. Any single pole overcurrent protection device (OCPD) rated at 125 A can be mounted in pairs, but cannot have an OCPD installed on either side of the pair.
2. Any single pole OCPD rated at 100 A and below can be mounted in any position without spacing.
3. The highest rated bullet fuse that can be used is 125 A. The highest rated single pole breakers that can be used for a load is 100 A. The highest rated single pole breaker that can be used for batteries is 125 A at temperatures below 131°F (55°C) and 100 A for temperatures above 131°F (55°C).

While these guidelines require some planning, they do not limit achieving the maximum 300 A capacity for any breaker size combination (except if many small breakers are used).

For Cordex® CXPS-E3 400 A Edge Power Systems

1. Any single pole overcurrent protection device (OCPD) rated at 125 A can be mounted in pairs, but cannot have an OCPD installed on either side of the pair.
2. Any single pole OCPD rated at 100 A and below can be mounted in any position without spacing.
3. The highest rated bullet fuse that can be used is 125 A. The highest rated single pole breakers that can be used for a load is 100 A. The highest rated single pole breaker that can be used for batteries is 125 A at temperatures below 131°F (55°C) and 100 A for temperatures above 131°F (55°C).

While these guidelines require some planning, they do not limit achieving the maximum 400 A capacity for any breaker size combination (except if many small breakers are used).

For Cordex® CXPS-E3 600 A Edge Power Systems

1. The highest rated single position fuse holder is 125 A.
2. The highest rated single pole breaker for a load is 100 A.
3. Any single pole breaker rated above 90 A must not have any overcurrent protection device (OCPD) installed in the positions on either side of it.
4. Any single pole breaker rated 90 A and below can be mounted in any position without spacing.
5. The single position fuse holder can be mounted without spacing (except in reference to item 2).

For Cordex® CXPS-E3 900 A Edge Power Systems

1. Any single pole overcurrent protection device (OCPD) rated at 125 A can be mounted in pairs, but cannot have an OCPD installed on either side of the pair.
2. Any single pole OCPD rated at 100 A and below can be mounted in any position without spacing.

3. The highest rated bullet fuse that can be used is 125 A. The highest rated single pole breakers that can be used for a load is 100 A. The highest rated single pole breaker that can be used for batteries is 125 A at temperatures below 131°F (55°C) and 100 A for temperatures above 131°F (55°C).

While these guidelines require some planning, they do not limit achieving the maximum 450 A capacity for any breaker size combination (except if many small breakers are used).

7.5.2 Load connections

For wire sizing refer to guidelines supplied with the load equipment.

Terminate distribution cabling with 0.25-inch to 0.625-inch center lugs for connecting to the power system distribution. Always make the return connection to the power system, and then verify the nut tightening torque before installing the hot connection as once the hot connection is in place it is difficult to access the return connection.

Always use the supplied hardware (nuts) for attaching the lugs. The supplied nuts have a serrated flange which eliminates the need for a second lock washer both allowing more threads to show after a completed connection and avoiding thin hardware which can fall through small gaps in the equipment covers.

Load and battery breaker return connections

Secure cables with two hole lugs to the 0.25-inch studs on 0.625-inch centers using the supplied hardware. Run cables directly out the back of the distribution panel.

Load and battery breaker hot connections

Secure cables with two hole lugs to the 0.25-inch studs on 0.625-inch centers using the supplied hardware. Run cables directly out the back of the distribution panel above the breaker return cables.



NOTICE

The 600A double distribution system can accomodate ⅜ inch studs on 1 inch centers for battery connections. For more information, refer to drawing 0250047-08 at the end of this document.

7.6 Alarm and signal connection

The I/O capabilities of the power system allow the user to extend various alarm or control signals to an external site monitor via output relays or monitor various analog and digital signals via analog and digital inputs.

For terminal block connections, the recommended wire sizes are 26 to 16 AWG (0.14 to 1.50 mm²) for the temperature range of 32°F to 167°F (0°C to 75°C) as per UL/CSA.



CAUTION

To reduce risk of fire, use only 26 AWG (0.14 mm²) or larger wire.

Route via wireways and use existing cable clamps or lances to secure to existing (factory) wire harness along with customer run signal wires. Ensure signal wires are routed along hinge point of front door so door opening and closing won't require excess wire slack.

Terminal block connections for the ADIO peripheral should be routed along the left side of the power system (looking at unit from front). Connections to the controller and ADIO peripheral should be routed along the right hand side of the power system. Refer to the customer connections (–08) drawing at the end of this document for details on terminal block assignments.




Figure 27: Alarm (relay) connections

7.6.1 Alarm (relay) outputs

Terminals provide contacts for extending various alarm or control signals. Each relay output can be wired for normally open (NO) or normally closed (NC) operation during an alarm or control condition. Relays can be programmed to energize or de-energize during an alarm condition. See the controller software manual for programming.

7.6.2 Digital inputs

The digital input channels are used to monitor various alarm and control signals. All input channels are voltage activated and accept a bipolar (negative or positive) DC signal directly.

7.6.3 Connection method

Typical Cordex® systems use the reset with **Hot** and trigger with ground connection. The digital input is wired in such a way that the **Hot** is wired directly into one of the input terminals; for example, negative input for 48V systems. The other input terminal is wired to the ground (common) of the system through a relay (dry contact—usually located on the equipment requiring monitoring). This method (see Figure 28) allows the digital input to receive (or not receive) a ground signal on an alarm.




Figure 28: Digital input connection method

Table M: Voltage level definitions for digital inputs		
Voltage range	**Voltage level considered as "0" (Off)**	**Voltage level considered as "1" (On)**
–60 to +60VDC (system voltage setting)	–1 to +1VDC	–60 to-5 or +5 to +60VDC

7.6.4 Programming the digital input

The digital input channels can be programmed for active high or active low. Active high indicates alarm on the presence of a ground signal and active low indicates alarm on the removal of a ground signal. See the controller software manual for detailed instruction on programming.

ATTENTION

Ensure that the correct polarity is used for all input cable terminations.

7.6.5 Analog inputs

The analog input channels are used to monitor various types of electrical signals. The analog channels are labeled to receive specific signals. The input cables should be bundled together and routed through the entry holes.

Default configurations and terminal numbers described in this chapter have been summarized in the drawings located at the end of this document.

7.7 Network and remote communication

The system can be set up, monitored and tested via an Ethernet IEEE 10/100/1000 BASE-T serial data connection and accessed via the controller web interface. Pin-outs are shown in the customer connections drawing.

Some standard scenarios are described:

- **Network connection:** The Ethernet port is designed to connect the controller to a user supplied network (TCP/IP supplied by the user) via a front panel RJ45 port. Use a standard network cable for this connection.
- **Local connection:** The Ethernet port can also be used for local access such as using a laptop computer. Use a standard Ethernet cable for this connection.

7.8 Connecting battery temperature sensor

Locate the battery temperature sensors from the ADIO peripheral coiled below the distribution panel. Uncoil and connect the temperature sensors to a battery termination post negative in each battery tray.




Figure 29: Battery temperature sensor



Figure 30: Battery temperature sensor, battery bay

7.8.1 Load distribution

Refer to guidelines supplied with the load equipment. Typically, distribution cables are sized to provide a 0.5V loop drop at full load and meet the ampacity requirements of the protection fuse or circuit breaker.

7.9 Signal wiring

1. Use the Form C relay contacts on the ADIO low voltage peripheral to extend various alarm or control signals to an external site monitor. Figure 32 shows the peripheral alarm relay pinouts. Table M lists the factory default settings.
2. Use 26 AWG (0.14 mm²) or larger wire.
3. Bundle signal wires together and route through the top of the bay.




Figure 31: Relay connections, not energized state




Figure 32: Alarm relay pinouts

Table N: Relay assignments

Channel description	Factory default designation
LCD fail alarm	Not configurable
Relay K1 to K5	LVD1 or not used
Relay K6 to K8	User configurable
Relay K9	AC MAINS HIGH/LOW alarm
Relay K10	SYSTEM MINOR alarm
Relay K11	SYSTEM MAJOR alarm
Relay K12	SYSTEM CRITICAL alarm

7.9.1 Relays

Relays can be programmed to be energized or not energized during an alarm condition. See the controller software manual for programming. Relays can be reassigned in the **Relays** table. From the controller's main **Dashboard** go to **Modules.** In the **CAN Modules** table, select the module and select the **Go To** button.

For more information, refer to the ADIO peripheral maintenance section of the controller software manual.

8. System startup

After completing the system installation and power system wiring, perform the following startup and test procedure to ensure proper operation.

1. Visually inspect the installation thoroughly.
2. Verify:
   - AC input power is off.
   - Battery modules are disconnected.
   - All breakers are off and no grasshopper made for telecom (GMT) fuses installed if any loads are connected.
   - All power modules are removed from the shelf.
3. Triple-check the polarity of all connections.
4. Install one rectifier module into the front left-most position using the side of the shelf as a guide.
   - Place the rectifier module on the shelf.
   - Slide the module into the back connector inside the shelf.
   - Apply pressure on the module front panel to engage the back connector in the shelf receptacle.
5. Verify that the AC input voltage is correct and that the breaker switch for the corresponding feeder breaker is **ON**. The power module OK LED will illuminate after a preset start delay.
6. Test the functionality of various module alarms and controls using the controller's built-in display or web interface.
7. Verify the correct battery polarity using a voltmeter. Ensure that no cells or batteries are reversed.
8. Connect the batteries to the output of the system.
9. Install the remaining power modules.
10. Configure the battery parameters according to the battery manufacturers recommendations. See the controller software manual for detailed instructions on how to configure the batteries.
11. From the **Systems > DC System > System Functions > Equalize & Boost** menu on the controller, set the float and equalize voltage to the levels specified by the battery manufacturer.
12. Use the controller to test the functionality of various module alarms and controls especially the battery breaker alarm test. Verify alarms are transmitted to site monitor.
13. Perform a load test with the system using a resistive load box.
14. Enable the temperature compensation feature in the **Systems > DC System > System Functions > Temperature Compensation** menu. Program the settings for slope and breakpoints (upper and lower) with respect to the specific batteries used.

8.9.1 Factory ranges and default values

Table N lists the rectifier module settings, ranges, and default values. Changes are made through the controller interface.

Table O: Rectifier module factory ranges and default values

Setting	Range (minimum to maximum)	Default
Float (FL) voltage	47.5 to 58.2 V	54 V
Equalize (EQ) voltage	49.8 to 60.2 V	55 V
Battery test (BT) voltage	44 to 52 V	46 V
Overvoltage protection (OVP)[1]	63 V	63 V
Current limit (CL)	23 to 100%	100%
Power limit (PL)	0 to 100%	100%
Module start delay	0 to 250 s	1 s
System start delay	0 to 600 s	0 s
Low voltage alarm (LVA)	42 to 52 V	44 V
High voltage alarm (HVA)	52 to 63 V	55.5 V
EQ timeout	1 to 2399 h	30 h
BT timeout	1 to 250 h	8 h
Softstart ramp-rate	Normal/Fast	Normal
Current limit and power limit alarm	Enable/Disable	Enable
Remote shutdown	Enable/Disable	Enable
Ramp test	Enable/Disable	Enable

[1] The overvoltage protection value cannot be set below the present system, FL, EQ, BT voltage setting or the safe mode voltage of 51.4 V.

9. Maintenance

Although very little maintenance is required with Cordex® power systems, routine checks and adjustments are recommended to ensure optimum system performance. Qualified service personnel should do the repairs. The following table lists a few maintenance procedures for this system. These procedures should be performed at least once a year.

To order more breakers refer to the options listed in the specifications. Always replace circuit breakers with the same type and rating.

Consult support or sales for all replacement parts.



WARNING

Use extreme care when working inside the unit while the system is energized. Do not make contact with live components or parts.



ATTENTION

Circuit cards, including semiconductor devices, can be damaged by static electricity. Always wear a grounded wrist strap when handling or installing circuit cards.





ATTENTION

Ensure redundant modules or batteries are used to eliminate the threat of service interruptions while performing maintenance on the system's alarms and control settings.

Table P: Sample maintenance log

Procedure	Date completed
Inspect all system connections. Re-torque if necessary.	
Verify alarm and control settings.	
Verify alarm relay operation.	
Clean ventilation openings of the modules.	

9.1 System controller lithium battery replacement

A removable CR2032 lithium battery is located at the top of the Cprdex® HP system controller it is designed to be field replaceable and can be easily removed with no tools. The battery life is rated up to three years, but should be replaced if the panel does not maintain date and time during power interruption. It is also recommended to replace when the lithium battery voltage is less than 2.6VDC.

Depress the two front panel latches and tilt the front panel forward and down. Remove the battery from the slot and replace with the same type of battery observing the correct polarity.

NOTICE

If the system controller is powered off when the battery is replaced, time will be lost. Once the system controller is powered on, reset the time.



Figure 33: System controller battery replacement

NOTICE

The EnVision™ Elite Touch controller utilizes a supercapacitor for backup of the real-time clock in the event of a transient event or power loss.

9.2 300 and 400 A LVD override operation

ATTENTION

Before removing a controller from a live system or performing controller maintenance, an external LVD override is required to avoid a disruption of service.

The LVD control functions are hardwired directly from the assigned relay output to an optional LVD override control located in the power system distribution panel below the breakers. The override bypasses the LVD auto control function.

Place the LVD control switch to the **OVERRIDE** position to keep the LVD contactor engaged.

To allow the controller to resume automatic control of the LVD contactor, check that the **AUTO IN** (green) LED is lit confirming that the controller will keep the LVD contactor engaged. Then you can return the LVD control switch to the **NORMAL** position.

9.3 600 A LVD override operation

Refer to 4.11 600 A LVD override on page 26 for more information.

ATTENTION

Do not leave the switch in the OVERRIDE position. Doing so may result in a complete discharge of the batteries during a power failure situation.

10. Troubleshooting

Shelves and modules are designed for simple installation and reliable, trouble-free operation.

In most cases the modules will recover from minor alarms and faults automatically. However under certain conditions the modules may need remote control. Under very rare cases the module may need a manual reset (remove and reinsert the module). In the unlikely event of a module failure, it may need replacement.

A shelf can accommodate up to four or five modules depending on the model and shelf. The modules have various LED status indicators that provide information about the system.

When the shelf system is used in conjunction with a controller, detailed system information and status can be easily obtained. Additional information can be obtained via the web interface using the Ethernet port.

The following tables provide a quick reference of the various LEDs and the corresponding states.

10.1 Cordex® HP Rectifier Module LEDs

Table Q: Cordex® HP rectifier module LED states

LED name	Color	State	Meaning
Alarm	**Red**	**Off**	Indicates no failure or fault in the module.
		Solid	Indicates the output has shutdown to protect property or personnel.
		Flashing	Indicates a communication failure persisting for five minutes. Indicates the locate module command is active.
AC	**Green**	**Off**	Indicates output is in an off state.
		Solid	Indicates output is driven.
		Flashing	Indicates the locate module command is active.
DC	**Green**	**Off**	Indicates a failure or fault with input.
		Solid	Indicates that input is functioning correctly.
		Flashing	Indicates the locate module command is active.

10.2 EnVision™ Elite Touch Controller LEDs

Table R: EnVision™ Elite Touch controller LED states

LED name	Color	State	Meaning
Major or critical alarm (bell icon)	**Red**	**Off**	Indicates no active alarms.
		Solid	Indicates one or more major or critical alarms. There can be minor alarms as well.
		Flashing	N/A
Minor alarm (caution icon)	**Yellow**	**Off**	Indicates no active alarms
		Solid	Indicates one or more minor alarms.
		Flashing	N/A

OK (OK icon)	**Green**	**Off**	N/A
		Solid	Indicates that there are no alarms.
		Flashing	Flashes during initial startup.

10.3 Cordex® CXC HP System Controller LEDs

Table S: Cordex® CXC HP system controller LED states

LED name	Color	State	Meaning
Major/critical alarm (bell icon)	**Red**	**Off**	Indicates no active alarms.
		Solid	Indicates one or more major/critical alarms. There can be minor alarms as well.
		Flashing	All LEDs cycle on initial startup.
Minor alarm (caution icon)	**Yellow**	**Off**	Indicates no active alarms
		Solid	Indicates one or more minor alarms.
		Flashing	All LEDs cycle on initial startup.
OK (OK icon)	**Green**	**Off**	N/A
		Solid	Indicates that there are no alarms.
		Flashing	All LEDs cycle on initial startup.

10.4 Cordex® HP L-ADIO Low Voltage Smart Peripheral LEDs

Table T: Cordex® HP L-ADIO low voltage smart peripheral LED states


LED name	Color	State	Meaning
LVD	**Yellow**	**Off**	Indicates the LVD override feature is disabled.
		Solid	Indicates the LVD override button has been selected and the feature is enabled.
		Flashing	N/A
Power	**Blue**	**Off**	Indicates no power to the device.
		Solid	Indicates power is present.
		Flashing	N/A
COMMS	**Green**	**Off**	Indicates no communication with the controller.
		Solid	Indicates the peripheral has been acquired by the controller.
		Flashing	The LED flashes in response to a module locate command from the controller.


10.5 LVD Override Board LEDs


Table U: LVD override board LED states


LED name	Color	State	Meaning
Bus	**Green**	**Off**	N/A
		Solid	Indicates the bus is connected to the LVD and has power.
		Flashing	N/A
Coil	**Green**	**Off**	N/A
		Solid	Indicates the LVD coil is energized. This requires the bus to have power and one of the controls (L-ADIO, REMOTE, or LVD Override) to be active.
		Flashing	N/A
O/R	**Yellow**	**Off**	N/A
		Solid	Indicates the override switch is in the override position. This should only be on during maintenance.
		Flashing	N/A


11. Technical drawings






CORDEX® CXPS-E3 900A EDGE POWER SYSTEM
CUSTOMER CONNECTIONS
SHEET 2 OF 3
DUAL CAN PORTS
FAIL ALARM RELAY
POWER INPUT
CORDEX® CXC HP CONTROLLER
USB (FRONT)
ETHERNET (FRONT)
CORDEX® HP L-ADIO MODULE (SHEET 3)
CORDEX® CXC HP CONTROLLER
ETHERNET (REAR)
USB (REAR)
0250042-08



CORDEX® CXPS-E3 900A EDGE POWER SYSTEM
CUSTOMER CONNECTIONS
SHEET 3 OF 3
CAN IN P/N 123456
CAN OUT P/N 123456
CAN RJ12 OFFSET P/N OUT
1. GND
2. CAN High
3. CAN NOT USED
4. CAN Low
5. CAN NOT USED
6. CAN NOT USED
CAN IN
CAN OUT
LVD POWER COMMS
RESET
LVD OVERRIDE
DO NOT USE. SEE MANUAL FOR LVD OVERRIDE INSTRUCTIONS
SOFTWARE LVD OVERRIDE FUNCTION
SOFT RESET
CORDEX® HP L-ADIO I/O SMART PERIPHERAL
TEMPERATURE INPUTS
VOLTAGE INPUTS
CURRENT INPUTS
FORM C RELAY OUTPUTS
DIGITAL INPUTS
FORM C RELAY OUTPUTS
TEMPERATURE INPUTS
POWER INPUT 10 to 60 Vdc
CXC HP L-ADIO
CORDEX® HP L-ADIO PERIPHERAL
CORDEX® CXC HP CONTROLLER (SHEET 2)
0250042-08



CORDEX® CXPS-E3 900A EDGE POWER SYSTEM
OUTLINE
SHEET 1 OF 1
21.08
7.38
19.23
24.30
100°
40.91
22.26
21.13
0250042-002 INDOOR
21.08
5.88
20.61
24.30
100°
40.91
22.26
21.13
0250042-001 OUTDOOR
0250042-06



TITLE:
OUTLINE DRAWING,
CXPS-E3 / CXDM-E3
DWG NO.
0250030-06
REV.
F
SHEET
1 OF 5
16.53
0.85
21.13
0.430
0.250
22.26
23.01
6.97
0.240
0250030-001
0250030-002
0250030-003
0250030-004
16.53
0.85
6.00
MID
MOUNT
REF
17.13
18.26
19.01
1.750
1.250
0250030-009
0250030-010
0250030-011
0250030-012


TITLE:
OUTLINE DRAWING,
CXPS-E3 / CXDM-E3
DWG NO.
0250030-06
REV.
F
SHEET
2 OF 5
16.53
0.85
21.13
0.430
0.250
22.26
23.01
8.72
0.240
0250030-005
0250030-006
0250030-007
0250030-008
16.53
0.85
6.00
MID
MOUNT
REF
17.13
18.26
19.01
1.750
1.250
0250030-013
0250030-014
0250030-015
0250030-016


16.53
0.85
21.13
0.430
0.250
22.26
23.01
0.240
5.22
0250030-017
0250030-019
16.53
0.85
6.00
MID
MOUNT
REF
17.13
18.26
19.01
1.250
1.750
0250030-018
0250030-020
TITLE:
OUTLINE DRAWING,
CXPS-E3 / CXDM-E3
DWG NO
0250030-06
REV.
F
SHEET
3 OF 5



TITLE:
OUTLINE DRAWING,
CXPS-E3 / CXDM-E3
DWG NO.
0250030-06
REV.
F
SHEET
4 OF 5
0250030-750
23"
0250030-750
19"
(19.80)
16.53
0.85
8.39
9.08
3.27
23.01
6.44
19.01
2.86
12.07
10.07
1.75
2X 2.00


TITLE:
OUTLINE DRAWING,
CXPS-E3 / CXDM-E3
DWG NO
0250030-06
REV.
F
SHEET
5 OF 5
0919006-004
(0250030-036 WITH 2X 350MCM BATTERY LANDING OPTION)
0919007-004
(0250036-037 WITH 2X 350MCM BATTERY LANDING OPTION)
0919006-003
(0250030-036 WITH 8X 2 AWG BATTERY LANDING OPTION)
0919007-003
(0250036-037 WITH 8X 2 AWG BATTERY LANDING OPTION)
0250030-036 & 0250030-037
FRONT VIEW
12.16
1.57
1.18
2X 2.93
15.91
9.97
2X 2.94
18.59
6.85
19.09
1.68
2X 4.14
0.430
0.250
22.26
23.01
0.240
8.72


CORDEX® CXPS-E3 (4 KW)
EDGE POWER SYSTEM
OUTLINE
SHEET 1 OF 1
17.130
16.45
5.90
MID
MOUNT
REF
1.30
19.009
18.259
9.99
8.24
3.50
1.25
0250029-002
0250029-004
21.13
16.56
6.00
MID
MOUNT
REF
1.19
23.01
22.26
1.75
1.25
0250029-001
0250029-003
0250029-005
0250029-006
0250029-007
0250029-008
0250029-06


CORDEX® CXPS-E3 (4 KW)
EDGE POWER SYSTEM
CUSTOMER CONNECTIONS

SHEET 1 OF 2




BREAKER RETURNS
1/4-20 HARDWARE ON 5/8" CENTERS


BREAKER LOAD OUTPUTS / BATTERY INPUTS
1/4-20 HARDWARE ON 5/8" CENTERS





TOP VIEW
DOOR, COVER AND DRESSER BAR REMOVED


0250029-08


CORDEX® CXPS-E3 (4 KW)
EDGE POWER SYSTEM
CUSTOMER CONNECTIONS
SHEET 2 OF 2
B
0.625
DETAIL B
Ø 2X 1/4-20
BATTERY & LOAD BREAKERS
WHERE APPLICABLE (5 POSITIONS)
LOAD BREAKERS (21 / 16 POSITIONS)
A
FRONT VIEW WITH DOOR REMOVED
OVERRIDE / AUTO
OVERRIDE ACTIVE (YELLOW)
LVD COIL POWER (GREEN)
BUS POWER (GREEN)
LVD COIL CONTROL (COM)
LVD COIL CONTROL (HOT)
LVD OVERRIDE SWITCH STATE(-)
LVD OVERRIDE SWITCH STATE(+)
DETAIL A
02500029-08



CORDEX® CXPS-E3 EDGE POWER SYSTEM
(19- and 23-inch)
CUSTOMER CONNECTIONS
SHEET 1 OF 4
CHASSIS GROUND
BREAKER RETURNS
1/4-20 HARDWARE ON 5/8" CENTERS
BATTERY & LOAD BREAKERS
(WHERE APPLICABLE)
LOAD BREAKERS
BREAKER OUTPUTS
1/4-20 HARDWARE ON 5/8" CENTERS
CHASSIS GROUND
0919XXX-XXX-08



CORDEX® CXPS-E3 EDGE POWER SYSTEM
(19- and 23-inch)
CUSTOMER CONNECTIONS
SHEET 2 OF 4
LVD OVERRIDE BOARD
FACTORY CONNECTIONS
L-ADIO / Controller POWER
LVD
L-ADIO I/O
COIL CONTROL JUMPER
CTRL (NO)
ENABLE (NC)
TB1
TB2
LVD OVERRIDE SWITCH STATE (+)
LVD OVERRIDE SWITCH STATE (-)
LVD COIL CONTROL (HOT)
LVD COIL CONTROL (COM)
CUSTOMER CONNECTIONS
OVERRIDE
AUTO
SW1
LVD OVERRIDE SWITCH
DS3
DS1
DS2
OVERRIDE ACTIVE (YELLOW)
LVD COIL POWER (GREEN)
BUS POWER (GREEN)
STATUS LEDS
0919XXX-XXX-08



CORDEX® CXPS-E3 (19- and 23-inch)
CUSTOMER CONNECTIONS
SHEET 3 OF 4
CAN IN
CAN OUT
P/N 123456
P/N 123456
CAN IN
CAN OUT
LVD POWER COMMS
RESET
LVD OVERRIDE
DO NOT USE. SEE MANUAL FOR LVD OVERRIDE INSTRUCTIONS
SOFTWARE LVD OVERRIDE FUNCTION
SOFT RESET
CAN RJ12 OFFSET P/N OUT
1.GND
2.CAN High
3.CAN NOT USED
4.CAN Low
5.CAN NOT USED
6.NOT NOT USED
NOTES:
1. RELAY K1 RESERVED FOR LVD CONTROL (IF EQUIPPED).
2. DIGITAL INPUTS D1-D2 RESERVED FOR DISTRIBUTION PANEL BREAKER / FUSE ALARMS.
3. DIGITAL INPUT D3 RESERVED FOR LVD OPEN ALARM (IF EQUIPPED).
4. VOLTAGE INPUTS V1-V2 RESERVED FOR BATTERY / LOAD VOLTAGE MONITORING.
5. CURRENT SHUNT INPUT I1 RESERVED FOR BATTERY / LOAD SHUNT MONITORING.
FORM C RELAY OUTPUTS
CURRENT INPUTS
VOLTAGE INPUTS
TEMPERATURE INPUTS
DIGITAL INPUTS
POWER INPUT 10-60Vdc
CXC HP L-ADIO
Cordex® HP L-ADIO I/O Peripheral
0919XXX-XXX-08



CORDEX® CXPS-E3 EDGE POWER SYSTEM
(19- and 23-inch)
CUSTOMER CONNECTIONS
CORDEX® HP L-ADIO PERIPHERAL
(SHEET 3)
CORDEX® CXC HP CONTROLLER
DUAL CAN PORTS
FAIL ALARM RELAY
POWER INPUT
CORDEX® CXC HP CONTROLLER
(RIGHT SIDE)
CORDEX® CXC HP CONTROLLER
(FRONT)
USB (FRONT)
ETHERNET (FRONT)
ETHERNET (REAR)
USB (REAR)
CORDEX® CXC HP CONTROLLER
(LEFT SIDE)
SHEET 4 OF 4
0919XXX-XXX-08


TITLE: OUTLINE, CXPS-E3 600			
SIZE: B	DWG NO: 0250047-06		REV: B
SCALE: 1:8		SHEET: 1 OF 1	













TITLE:
CUSTOMER CONNECTIONS,
CXPS-E3-600
DWG NO
0250047-08
REV.
B
SHEET
1 OF 4
BREAKER RETURNS 36 & 37 ARE BLOCKED.
SEE DETAIL B FOR ALTERNATIVE RETURN LANDING.
LOAD BREAKERS 1-26
SECTION A-A
CHASSIS GROUND
1/4-20 HARDWARE
ON 5/8" CENTERS.
MIRRORED ON
OTHER SIDE
LOAD BREAKER RETURNS
1/4-20 HARDWARE ON 5/8" CENTERS
LOAD BREAKER OUTPUTS
1/4-20 HARDWARE ON 5/8" CENTERS
LOAD BREAKERS 27-52
(400A MAX CAPACITY PER LOAD BREAKER TIER. REFER TO MANUAL)


TITLE:
CUSTOMER CONNECTIONS,
CXPS-E3-600
DWG NO.
0250047-08
REV.
B
SHEET
2 OF 4
*HOT LANDING
(LVLD)
2X ALTERNATE
LOAD BREAKER RETURN LANDINGS
*RETURN LANDING
HORIZONTAL
ADAPTER
OPTION
B
DETAIL B
*LANDINGS FOR 2 X 4/0 BATTERY
LUGS, 3/8-16 UNC STUDS ON 1" CENTERS,
& 4 X 2AWG BATTERY LUGS 1/4-20 UNC
STUDS ON 5/16" CENTERS.
SHOWN WITHOUT BLVD OPTION
2X ALTERNATE
LOAD BREAKER RETURN LANDINGS
*RETURN LANDING
HORIZONTAL
ADAPTER
OPTION
B
*HOT LANDING
(BLVD)
DETAIL C
SHOWN WITH BLVD OPTION


LVLD OVERRIDE INTERFACE
(REFER TO MANUAL)
BLVD/LVLD OVERRIDE INTERFACE
(REFER TO MANUAL)
10 POSITION GMT FUSE DISTRIBUTION OPTION
(SHEET 4)
CORDEX HP-LAD/O
(SHEET 4)
CONTROLLER
DUAL CAN PORTS
FAIL ALARM RELAY
POWER INPUT
USB
(FRONT)
ETHERNET
(FRONT)
CORDEX HP CONTROLLER
ETHERNET (REAR)
USB (REAR)
TITLE:
CUSTOMER CONNECTIONS,
CXPS-E3-600
DWG NO.
0250047-08
REV.
B
SHEET
3 OF 4


10 POSITION GMT FUSE DISTRIBUTION OPTION
CORDEX HP-LADIO
CONTROLLER (SHEET 3)
FUSE FAIL ALARM
DISTRIBUTION COMMON
DISTRIBUTION HOT
DISTRIBUTION HOT
DISTRIBUTION COMMON
10 POSITION GMT FUSE DISTRIBUTION OPTION 30A MAX (SEE MANUAL)
CAN IN
PINOUT 123456
CAN OUT
PINOUT 123456
CAN RJ12 OFFSET P/N OUT
1. GND
2. CAN High
3. CAN NOT USED
4. CAN Low
5. CAN NOT USED
6. CAN NOT USED
DO NOT USE SEE MANUAL FOR LVD OVERRIDE INSTRUCTIONS
SOFTWARE LVD OVERRIDE FUNCTION
SOFT RESET
CAN IN
CAN OUT
LVD
POWER
COMMS
LVD OVERRIDE
RESET
cordex HP
CXC HP L-ADIO
TEMPERATURE INPUTS
VOLTAGE INPUTS
CURRENT INPUTS
FORM C RELAY OUTPUTS
DIGITAL INPUTS
FORM C RELAY OUTPUTS
TEMPERATURE INPUTS
POWER INPUT 10-60 VDC
CORDEX HP L-ADIO I/O MODULE
NOTE: SOME I/O ARE RESERVED FOR INTERNAL USE. REFER TO MANUAL.
TITLE: CUSTOMER CONNECTIONS, CXPS-E3-600
DWG NO. 0250047-08
REV. B
SHEET 4 OF 4



Alpha Technologies Ltd. | 7700 Riverfront Gate, Burnaby, BC V5J 5M4 Canada
Toll Free North America: +1 800-667-8743 | Outside North America +1 604-436-5547 | Technical Support +1 888-462-7487
For more information, visit our website at **EnerSys.com**
© 2026 Alpha Technologies Ltd., an EnerSys company. All Rights Reserved. Trademarks and logos are the property of EnerSys and its affiliates except for Bluetooth®, CSA®, IEEE®, OSHA®, National Electrical Code®, NO-OX-ID®, Scotch-Brite®, and UL® which are not the property of EnerSys.
Subject to revisions without prior notice. E. & O.E.

9400016-J0 REV J (09/2026)