

EnerSys®

Power/Full Solutions



SuperSafe®
SBSXC

Performance Data



Visit us at www.enersys.com



EnerSys World Headquarters
2366 Bernville Road, Reading,
PA 19605, USA
Tel: +1-610-208-1991 / +1-800-538-3627

EnerSys EMEA
EH Europe GmbH,
Baarerstrasse 18,
6300 Zug, Switzerland

EnerSys Asia
152 Beach Road,
Gateway East Building #11-08
Singapore 189721
Tel: +65 6416 4800

Contact: